



# DCP-555

Digital Conferencing Processor with VoIP

Third party API documentation v1.7





## Table of contents

Overview .....	8
DCP 555 API requirements.....	8
1. Login / Logout .....	8
1.1. Login.....	8
1.2. Logout .....	8
2. Configure Input Channels .....	9
2.1. Select input channel routing .....	9
2.2. Configure/ Select Blulink channel.....	9
2.3. Set preamp gain of analog input channel .....	10
2.4. Enable/Disable phantom power of input channel.....	10
3. Configure Output Channels.....	11
3.1. Select AES channel .....	11
3.2. Select Analog channel.....	11
3.3. Select USB channel.....	12
3.4. Select VoIP channel.....	12
3.5. Select blulink slot number .....	13
3.6. Select Blulink channel .....	13
3.7. Set Polarity .....	14
4. AEC Screen (Input channels) .....	15
4.1. Enable /Disable AEC .....	15
4.2. Enable /Disable AGC .....	15
4.3. Set Minimum gain of AGC.....	16
4.4. Set Maximum gain of AGC .....	16
4.5. Set target level of AGC.....	17
4.6. Set Activation threshold value of AGC.....	17
4.7. Set NLP strength value of AGC.....	18
4.8. Get ERL value of AGC .....	18
4.9. Get ERLE value of AGC .....	19
5. Automixer Screen.....	20
5.1. Set master gain .....	20
5.2. Get master level .....	20
5.3. Mute master .....	21



---

5.4.	Set Ratio (Slope).....	21
5.5.	Set Speed .....	22
5.6.	Set Automixer Input gain .....	22
5.7.	Mute Input channel of Automixer .....	23
5.8.	Set Input channel OffGain of Automixer.....	23
5.9.	Get Input channel OpenMeter of Automixer .....	24
5.10.	Set Input channel Override of Automixer .....	25
5.11.	Set Solo in Automixer.....	25
5.12.	Set Automixer Input Connection .....	26
5.13.	Set Automixer Output Connection .....	26
5.14.	Set Automixer (1-4) name.....	27
6.	Control Compressor parameters .....	28
6.1.	Set Bypass value.....	28
6.2.	Set Threshold value.....	28
6.3.	Set Ratio value .....	29
6.4.	Set Gain value .....	29
6.5.	Get GainReduction value .....	30
6.6.	Get InputLevel value .....	30
6.7.	Set Attack value .....	31
6.8.	Set Release value .....	31
7.	Control Limiter parameters .....	32
7.1.	Set Bypass value.....	32
7.2.	Set Threshold value.....	32
7.3.	Get GainReduction value .....	33
7.4.	Get InputLevel value .....	33
7.5.	Set Attack value .....	34
7.6.	Set Release value .....	34
8.	Configure channel – AES67 .....	35
8.1.	Set Frame Rate .....	35
8.2.	Set DelayTime .....	35
8.3.	Set Processing .....	36
9.	Schematic Screen .....	37
9.1.	Get meter data of input channel before processing.....	37



---

9.2.	Get meter data of input channel after processing.....	37
9.3.	Set Mute/Unmute of Input channel .....	38
9.4.	Set level of Input channel .....	38
9.5.	Enable PEQ of Input channel.....	39
9.6.	Enable Bypass (Compressor) of Input channel .....	39
9.7.	Get meter data of output channel before processing.....	40
9.8.	Get meter data of output channel after processing .....	40
9.9.	Set Mute/Unmute of output channel .....	41
9.10.	Set level (Gain) of output channel .....	41
9.11.	Enable PEQ of Input channel.....	42
9.12.	Enable Bypass (Compressor) of Input channel .....	42
10.	PEQ Screen.....	43
10.1.	Set HPFrequency of Input channel.....	43
10.2.	Set HPType of Input channel.....	43
10.3.	Enable/Disable ParametricEQ of Input channel .....	44
10.4.	Reset/Restore all 4 bands value of Input channel .....	44
10.5.	Set Frequency of Band (1-4) of Input channel .....	45
10.6.	Set Gain of Band (1-4) of Input channel.....	45
10.7.	Set Q of Band (1-4) of Input channel .....	46
10.8.	Set Slope of Band (1-4) of Input channel .....	46
10.9.	Set Type of Band (1-4) of Input channel .....	47
10.10.	Set HPFrequency of Output channel.....	47
10.11.	Set HPType of Output channel.....	48
10.12.	Enable/Disable ParametricEQ of Output channel.....	49
10.13.	Reset/Restore all 4 bands value of Output channel .....	49
10.14.	Set Frequency of Band (1-4) of Output channel .....	50
10.15.	Set Gain of Band (1-4) of Output channel.....	50
10.16.	Set Q of Band (1-4) of Output channel .....	51
10.17.	Set Slope of Band (1-4) of Output channel .....	51
10.18.	Set Type of Band (1-4) of Output channel .....	52
11.	Configure Matrix Router .....	53
11.1.	Select/Assign channel in Input channel (1-28).....	53
11.2.	Select/Assign channel in Output channel (1-12).....	53



---

11.3.	Select/Assign input channel in Automixer (1-4) .....	53
11.4.	Select/Assign output channel in Automixer (1-4).....	54
11.5.	Set MasterGain of Automixer (1-4) (Same as section 5.1).....	54
11.6.	Set Speed of Automixer (1-4) (Same as section 5.5).....	55
11.7.	Set Ratio (Slope) of Automixer (1-4) (Same as section 5.4) .....	55
11.8.	Mute Automixer (1-4) (Same as section 5.3) .....	56
12.	BLU Link Settings.....	57
12.1.	Read version.....	57
12.2.	Read Master MAC address.....	57
12.3.	Read Master Priority .....	57
12.4.	Read Sample Rate .....	58
12.5.	Set Priority.....	58
12.6.	Read Input port status .....	59
12.7.	Read Output port status .....	59
12.8.	Read Input correct count .....	60
12.9.	Read Output correct count .....	60
12.10.	Read Input error count .....	61
12.11.	Read Output error count .....	61
12.12.	Reset Input error.....	62
12.13.	Reset Output error.....	62
13.	Device Settings.....	63
13.1.	Disable/Set Home screen timeout value .....	63
13.2.	Disable/Set Backlight timeout value .....	63
13.3.	Lock/Unlock Front panel.....	64
13.4.	Subscribe Firmware update status .....	64
13.5.	Subscribe / Unsubscribe version value .....	64
14.	Exec Commands .....	65
14.1.	Save Configuration.....	65
14.2.	Restore Configuration.....	65
14.3.	Create Configuration.....	66
14.4.	Validate Configuration .....	66
14.5.	Rename Configuration .....	67
14.6.	Reconfigure mono-stereo .....	67



---

14.7.	Change password .....	68
14.8.	Login.....	68
14.9.	Start firmware update.....	69
14.10.	Cancel firmware update.....	69
14.11.	Locate On/Off.....	70
14.12.	Factory reset .....	70
14.13.	Change IP Address.....	70
15.	Network Settings.....	71
15.1.	Network configuration of Port A (AES67) .....	71
15.2.	Network Configuration of Port B (VoIP).....	71
16.	VoIP settings (VoIP Screen).....	72
16.1.	Get account status .....	72
16.2.	Set user name .....	72
16.3.	Set Authentication user name .....	73
16.4.	Set Password.....	73
16.5.	Set Display name.....	74
16.6.	Set Domain value .....	74
16.7.	Enable/Disable Stun.....	75
16.8.	Enable/Disable “Register with domain” option.....	75
16.9.	Set Registration life value .....	76
16.10.	Set Registration retry value .....	76
16.11.	Set Proxy address.....	77
16.12.	Set Proxy port.....	77
16.13.	Set Signaling port .....	78
16.14.	Set SRTP Preference.....	78
16.15.	Set RTP Port .....	79
16.16.	Set RTP Port end .....	79
16.17.	Set Ring type .....	80
16.18.	Set AutoAnswerAfter option.....	80
16.19.	Set DTMFMode option.....	81
16.20.	Enable/Disable DTMFToneMute option .....	81
16.21.	Enable/Disable DTMFFixedLength option .....	82
16.22.	Set DTMFOnTime value (ms) .....	82



---

16.23.	Set DTMFOffTime value (ms) .....	83
16.24.	Enable/Disable Session timer .....	83
16.25.	Set DefaultTimer value.....	84
16.26.	Set MinimumTimer value.....	84
16.27.	Enable/Disable KeepAlive option.....	85
16.28.	Set KeepAliveInterval value .....	85
16.29.	Enable/Disable AutoAnswer .....	86
16.30.	Enable/Disable DND.....	86
16.31.	Increase/Decrease Volume (Set RXGain).....	87
16.32.	Set TXGain.....	87
16.33.	Set TXMute.....	88
16.34.	Set Ring volume .....	88
16.35.	Set DTMF volume .....	89
16.36.	Get VoIP line status.....	89
16.37.	Get CallerId .....	90
16.38.	Get Dial number.....	90
16.39.	Get CallStatus.....	91
16.40.	Get TxLevel.....	91
16.41.	Get RxLevel .....	92
16.42.	Set Key pressed value .....	92
16.43.	Dial (Call).....	93
16.44.	Hangup/Reject the call.....	94
16.45.	Hold the call .....	94
16.46.	Redial the number .....	95
16.47.	Resume the call.....	96
16.48.	Answer the call.....	96
16.49.	Delete dial number field .....	97
16.50.	Set Transport type (General VoIP settings screen).....	98
16.51.	Set T1 Timer .....	98
16.52.	Set T2 Timer .....	99
16.53.	Set T4 Timer .....	99
16.54.	Set TD Timer.....	99
16.55.	Set RPort .....	100



---

16.56.	Set Stun Port .....	100
16.57.	Set Stun Server.....	100
16.58.	Get MAC address .....	101
17.	Examples (Websocket).....	102
17.1.	Initializing connection steps.....	102
17.2.	Setting a value.....	102
17.3.	Getting a value .....	102
17.4.	Subscription steps .....	102
17.5.	Remove Subscription .....	103
18.	Examples (TCP via Telnet) .....	104
18.1.	Initialize TCP connection.....	104
18.1.1.	By using Putty tool .....	104
18.1.2.	By using CMD .....	104
18.2.	Login to DCP 555 device.....	105
18.3.	Send Commands .....	105

# Overview

This is the DCP 555 API Guide. It is intended for developers who are needing to integrate and communicate with DCP 555. This document assumes familiarity with JSON, HTTP, REST web services, and some programming language (Java, C#, TypeScript, etc.).

There are two ways to communicate with DCP 555 device by using listed APIs in this document–

- a) **WebSocket** (please refer section 17)
- b) **TCP** (please refer section 18)

## DCP 555 API requirements

API described in this document are implemented in DCP 555 v1.1 and newer. No language bindings for client development are provided. Developers can use their language of choice to consume these APIs.

### 1. Login / Logout

#### 1.1. Login

<b>API : HTTP request</b>  http://<hostname>/api/access/login?account=<USERNAME>&password=<PASSWORD>	RequestMethod: GET  RequestProperty: "Content-Type", "application/json"									
<b>Parameters :</b>  <table border="1"><thead><tr><th>Name</th><th>Values/range</th><th>Description</th></tr></thead><tbody><tr><td>Username</td><td></td><td></td></tr><tr><td>Password</td><td></td><td></td></tr></tbody></table>	Name	Values/range	Description	Username			Password			<b>Query/Command :</b>  http://<hostname>/api/access/login?account=<USERNAME>&password=<PASSWORD>  <b>Response :</b>  {"sessionID":"2d5de431-8df4-417d-897d-fd171cf890d6"}
Name	Values/range	Description								
Username										
Password										

#### 1.2. Logout

<b>API : HTTP request</b>  http://<hostname>/api/access/logout?sessionID=%5Bobject%20Object%5D	RequestMethod: GET  RequestProperty: "Cookie", "sessionID : <sessionId>"						
<b>Parameters :</b>  <table border="1"><thead><tr><th>Name</th><th>Values/range</th><th>Description</th></tr></thead><tbody><tr><td>SessionID</td><td></td><td></td></tr></tbody></table>	Name	Values/range	Description	SessionID			<b>Query/Command :</b>  <b>Response :</b>
Name	Values/range	Description					
SessionID							

## 2. Configure Input Channels

### 2.1. Select input channel routing

<b>API :</b>  \Config\MatrixRouter\InputChannel_#(channel number*)_RoutingSelection	Example – Select Analog channel (4 <sup>th</sup> ) at 28 <sup>th</sup> Input channel  <i>Input channel number – 28</i> <i>Value – 20 (Analog channel number 4)</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>1-28</td> <td>channel number need to be replaced with actual channel number 0 –None 1-16 -- AES 17-32 -- Analog 33-64 -- Blulink 65-66 -- USB 67-70 -- VoIP 71 – Signal generator</td> </tr> <tr> <td>value</td> <td>0-71</td> <td></td> </tr> <tr> <td>Format</td> <td>Number</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	channel number	1-28	channel number need to be replaced with actual channel number 0 –None 1-16 -- AES 17-32 -- Analog 33-64 -- Blulink 65-66 -- USB 67-70 -- VoIP 71 – Signal generator	value	0-71		Format	Number	Format type	<b>Query/Command :</b>  set [{"path":"/Config/MatrixRouter/InputChannel_28_RoutingSelection", "value":20, "format":"Number"}]  <b>Response :</b>  @set {"format":"Number", "path":"/Config/MatrixRouter/InputChannel_28_RoutingSelection", "value":20}
Name	Values/range	Description											
channel number	1-28	channel number need to be replaced with actual channel number 0 –None 1-16 -- AES 17-32 -- Analog 33-64 -- Blulink 65-66 -- USB 67-70 -- VoIP 71 – Signal generator											
value	0-71												
Format	Number	Format type											

### 2.2. Configure/ Select Blulink channel

<b>API :</b>  \Config\Blulink\Channel_#(blulink slot number)_InputAssignment	Example – Select blulink channel at 6 <sup>th</sup> Input channel  <i>Input channel number – 6</i> <i>Value – 256 (blulink channel number 4)</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>blulink slot number</td> <td>1-256</td> <td>Blulink slot number to be replaced with actual blulink channel number</td> </tr> <tr> <td>value</td> <td>33-64</td> <td>Blulink channel number</td> </tr> <tr> <td>Format</td> <td>Number</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	blulink slot number	1-256	Blulink slot number to be replaced with actual blulink channel number	value	33-64	Blulink channel number	Format	Number	Format type	<b>Query/Command :</b>  set [{"path":"/Config/MatrixRouter/InputChannel_6_RoutingSelection", "value":38, "format":"Number"}, {"path":"/Config/Blulink/Channel_6_InputAssignment", "value":256, "format":"Number"}]  <b>Response :</b>  @set {"format":"Number", "path":"/Config/MatrixRouter/InputChannel_4_RoutingSelection", "value":17}
Name	Values/range	Description											
blulink slot number	1-256	Blulink slot number to be replaced with actual blulink channel number											
value	33-64	Blulink channel number											
Format	Number	Format type											

## 2.3. Set preamp gain of analog input channel

<b>API :</b>  \Config\AnalogSettings\Channel_#(channel number*)_InputGain			Example – Set preamp gain of Input channel 5 <i>channel number – 5</i> <i>Value – 18</i>												
<b>Parameters :</b>  <table border="1"><thead><tr><th>Name</th><th>Values/range</th><th>Description</th></tr></thead><tbody><tr><td>channel number</td><td>1-28</td><td>channel number need to be replaced with actual channel number</td></tr><tr><td>value</td><td>0-30</td><td>Gain value</td></tr><tr><td>Format</td><td>Number</td><td>Format type</td></tr></tbody></table>			Name	Values/range	Description	channel number	1-28	channel number need to be replaced with actual channel number	value	0-30	Gain value	Format	Number	Format type	<b>Query/Command :</b>  set [{"path":"/Config/AnalogSettings/Channel_5_InputGain","value":18,"format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/AnalogSettings/Channel_5_InputGain","value":18}
Name	Values/range	Description													
channel number	1-28	channel number need to be replaced with actual channel number													
value	0-30	Gain value													
Format	Number	Format type													

## 2.4. Enable/Disable phantom power of input channel

<b>API :</b>  \Config\AnalogSettings\Channel_#(channel number*)_PhantomPower .			Example – Enable Phantom power of Input channel 5 <i>channel number – 5</i> <i>Value – 1</i>												
<b>Parameters :</b>  <table border="1"><thead><tr><th>Name</th><th>Values/range</th><th>Description</th></tr></thead><tbody><tr><td>channel number</td><td>1-28</td><td>channel number need to be replaced with actual channel number</td></tr><tr><td>value</td><td>0 - 1</td><td>0 – disable 1-enable</td></tr><tr><td>Format</td><td>Number</td><td>Format type</td></tr></tbody></table>			Name	Values/range	Description	channel number	1-28	channel number need to be replaced with actual channel number	value	0 - 1	0 – disable 1-enable	Format	Number	Format type	<b>Query/Command :</b>  set [{"path":"/Config/AnalogSettings/Channel_5_PhantomPower","value":1,"format":"Norm"}]  <b>Response :</b>  @set {"format":"Norm","path":"/Config/AnalogSettings/Channel_5_PhantomPower","value":1}
Name	Values/range	Description													
channel number	1-28	channel number need to be replaced with actual channel number													
value	0 - 1	0 – disable 1-enable													
Format	Number	Format type													

### 3. Configure Output Channels

#### 3.1. Select AES channel

<b>API :</b>  \Config\MatrixRouter\AES67_Out_#(AES channel number)_RoutingSelection	Example – Select AES channel (2 <sup>nd</sup> ) at 1 <sup>st</sup> Output channel  <i>AES channel number – 2</i> <i>value – 1</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>AES channel number</td> <td>1-8</td> <td>Aes channel number need to be replaced with actual channel number</td> </tr> <tr> <td>value</td> <td>0-12</td> <td>Output channel number</td> </tr> <tr> <td>Format</td> <td>Number</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	AES channel number	1-8	Aes channel number need to be replaced with actual channel number	value	0-12	Output channel number	Format	Number	Format type	<b>Query/Command :</b>  set [{"path":"/Config/MatrixRouter/AES67_Out_2_RoutingSelection","value":1,"format":"Number"}]  <b>Response :</b>  set [{"path":"/Config/MatrixRouter/AES67_Out_2_RoutingSelection","value":1,"format":"Number"}]
Name	Values/range	Description											
AES channel number	1-8	Aes channel number need to be replaced with actual channel number											
value	0-12	Output channel number											
Format	Number	Format type											

#### 3.2. Select Analog channel

<b>API :</b>  \Config\MatrixRouter\Analog_Out_#(analog channel number)_RoutingSelection	Example – Select analog channel (8th) at 2nd Output channel  <i>analog channel number – 8</i> <i>value – 2</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>analog channel number</td> <td>1-8</td> <td>analog channel number need to be replaced with actual channel number</td> </tr> <tr> <td>value</td> <td>0-12</td> <td>Output channel number</td> </tr> <tr> <td>Format</td> <td>Number</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	analog channel number	1-8	analog channel number need to be replaced with actual channel number	value	0-12	Output channel number	Format	Number	Format type	<b>Query/Command :</b>  set [{"path":"/Config/MatrixRouter/Analog_Out_8_RoutingSelection","value":2,"format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/MatrixRouter/Analog_Out_8_RoutingSelection","value":2"}
Name	Values/range	Description											
analog channel number	1-8	analog channel number need to be replaced with actual channel number											
value	0-12	Output channel number											
Format	Number	Format type											

### 3.3. Select USB channel

<b>API :</b>  \Config\MatrixRouter\USB_Out_#(USB channel number)_RoutingSelection	Example – Select USB channel (2nd) at 2nd Output channel  <i>USB channel number – 2</i> <i>value – 2</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>USB channel number</td> <td>1-2</td> <td>analog channel number need to be replaced with actual channel number</td> </tr> <tr> <td>value</td> <td>0-12</td> <td>Output channel number</td> </tr> <tr> <td>Format</td> <td>Number</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	USB channel number	1-2	analog channel number need to be replaced with actual channel number	value	0-12	Output channel number	Format	Number	Format type	<b>Query/Command :</b>  set [{"path":"/Config/MatrixRouter/USB_Out_2_RoutingSelection","value":2,"format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/MatrixRouter/USB_Out_2_RoutingSelection","value":"2"}
Name	Values/range	Description											
USB channel number	1-2	analog channel number need to be replaced with actual channel number											
value	0-12	Output channel number											
Format	Number	Format type											

### 3.4. Select VoIP channel

<b>API :</b>  \Config\MatrixRouter\VOIP_Out_#(voip channel number)_RoutingSelection	Example – Select VoIP channel (2nd) at 12 <sup>th</sup> Output channel  <i>VoIP channel number – 2</i> <i>value – 12</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>voip channel number</td> <td>1-4</td> <td>voip channel number need to be replaced with actual channel number</td> </tr> <tr> <td>value</td> <td>0-12</td> <td>Output channel number</td> </tr> <tr> <td>Format</td> <td>Number</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	voip channel number	1-4	voip channel number need to be replaced with actual channel number	value	0-12	Output channel number	Format	Number	Format type	<b>Query/Command :</b>  set [{"path":"/Config/MatrixRouter/VOIP_Out_2_RoutingSelection","value":12,"format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/MatrixRouter/VOIP_Out_2_RoutingSelection","value":"12"}
Name	Values/range	Description											
voip channel number	1-4	voip channel number need to be replaced with actual channel number											
value	0-12	Output channel number											
Format	Number	Format type											

### 3.5. Select blulink slot number

<b>API :</b>  \Config\MatrixRouter\Blulink_Out_#(blulink slot selection)_RoutingSelection	Example – Select VoIP channel (2nd) at 12 <sup>th</sup> Output channel  <i>VoIP channel number – 2</i> <i>value – 12</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>blulink slot selection</td> <td>1-32</td> <td>blulink slot selection need to be replaced with actual blulink slot number</td> </tr> <tr> <td>value</td> <td>0-12</td> <td>Output channel number</td> </tr> <tr> <td>Format</td> <td>Number</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	blulink slot selection	1-32	blulink slot selection need to be replaced with actual blulink slot number	value	0-12	Output channel number	Format	Number	Format type	<b>Query/Command :</b>  set [{"path":"/Config/MatrixRouter/VOIP_Out_2_RoutingSelection","value":12,"format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/MatrixRouter/VOIP_Out_2_RoutingSelection","value":"12"} }
Name	Values/range	Description											
blulink slot selection	1-32	blulink slot selection need to be replaced with actual blulink slot number											
value	0-12	Output channel number											
Format	Number	Format type											

### 3.6. Select Blulink channel

<b>API :</b>  \Config\Blulink\Channel_#(blulink slot number)_OutputAssignment	Example – Select Blulink channel (3rd) at 12 <sup>th</sup> Output channel  <i>Blulink channel number – 3</i> <i>value – 12</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>blulink slot number</td> <td>1-256</td> <td>blulink slot number need to be replaced with actual blulink channel number</td> </tr> <tr> <td>value</td> <td>0-12</td> <td>Output channel number</td> </tr> <tr> <td>Format</td> <td>Number</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	blulink slot number	1-256	blulink slot number need to be replaced with actual blulink channel number	value	0-12	Output channel number	Format	Number	Format type	<b>Query/Command :</b>  set [{"path":"/Config/Blulink/Channel_1_OutputAssignment","value":3,"format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/MatrixRouter/BluLink_Out_1_RoutingSelection","value":"0"} }
Name	Values/range	Description											
blulink slot number	1-256	blulink slot number need to be replaced with actual blulink channel number											
value	0-12	Output channel number											
Format	Number	Format type											

### 3.7. Set Polarity

<b>API :</b>  \Config\Output#(output channel number)Level/Channel_1_Polarity			Example – Enable/Set polarity of output channel 4 <i>Output channel number – 4</i> <i>Value - 1</i>
<b>Parameters :</b>			<b>Query/Command :</b>
<b>Name</b>	<b>Values/range</b>	<b>Description</b>	<b>Query/Command :</b> <pre>set [{"path":"/Config/Output4Level/Channel_1_Polarity","value":1,"format":"Norm"}]</pre> <b>Response :</b> <pre>@set {"format":"Norm","path":"/Config/Output4Level/Channel_1_Polarity","value":1}</pre>

## 4. AEC Screen (Input channels)

### 4.1. Enable /Disable AEC

<b>API :</b>  \Config\MatrixRouter\Channel_#(channelnumber)_AECEnable	Example – Enable AES for Input channel 1 <i>channel number – 1</i> <i>Value - 1</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channelnumber</td> <td>1-12</td> <td>channel number has to be replaced with actual input channel number</td> </tr> <tr> <td>value</td> <td>0-1</td> <td>On/Off</td> </tr> <tr> <td>Format</td> <td>Norm</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	channelnumber	1-12	channel number has to be replaced with actual input channel number	value	0-1	On/Off	Format	Norm	Format type	<b>Query/Command :</b>  set [{"path":"/Config/MatrixRouter/Channel_1_AECEnable","value":1,"format":"Norm"}]  <b>Response :</b>  @set {"format":"Norm","path":"/Config/MatrixRouter/Channel_1_AECEnable","value":"1"}
Name	Values/range	Description											
channelnumber	1-12	channel number has to be replaced with actual input channel number											
value	0-1	On/Off											
Format	Norm	Format type											

### 4.2. Enable /Disable AGC

<b>API :</b>  \Config\MatrixRouter\Channel_#(channelnumber)_AGCEnable	Example – Enable AGS for Input channel 1 <i>channel number – 1</i> <i>Value - 1</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channelnumber</td> <td>1-12</td> <td>channel number has to be replaced with actual input channel number</td> </tr> <tr> <td>value</td> <td>0-1</td> <td>On/Off</td> </tr> <tr> <td>Format</td> <td>Norm</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	channelnumber	1-12	channel number has to be replaced with actual input channel number	value	0-1	On/Off	Format	Norm	Format type	<b>Query/Command :</b>  set [{"path":"/Config/MatrixRouter/Channel_1_AGCEnable","value":1,"format":"Norm"}]  <b>Response :</b>  @set {"format":"Norm","path":"/Config/MatrixRouter/Channel_1_AGCEnable","value":"1"}
Name	Values/range	Description											
channelnumber	1-12	channel number has to be replaced with actual input channel number											
value	0-1	On/Off											
Format	Norm	Format type											

### 4.3. Set Minimum gain of AGC

<b>API :</b>  \Config\MatrixRouter\Channel_#(channel number)_AGC_MinGain			Example – Set minimum gain of AGC  <i>channel number – 3</i> <i>Value – (-20)</i>												
<b>Parameters :</b>  <table border="1"><thead><tr><th>Name</th><th>Values/range</th><th>Description</th></tr></thead><tbody><tr><td>channelnumber</td><td>1-12</td><td>channel number has to be replaced with actual input channel number</td></tr><tr><td>value</td><td>(-20) - 0</td><td></td></tr><tr><td>Format</td><td>Default</td><td>Format type</td></tr></tbody></table>			Name	Values/range	Description	channelnumber	1-12	channel number has to be replaced with actual input channel number	value	(-20) - 0		Format	Default	Format type	<b>Query/Command :</b>  set [{"path":"/Config/MatrixRouter/Channel_3_AGC_MinGain","value": "-20", "format": "Default"}]  <b>Response :</b>  @set {"path":"/Config/MatrixRouter", "value": {"Channel_3_AGC_MinGain": "-20dB"}}
Name	Values/range	Description													
channelnumber	1-12	channel number has to be replaced with actual input channel number													
value	(-20) - 0														
Format	Default	Format type													

### 4.4. Set Maximum gain of AGC

<b>API :</b>  \Config\MatrixRouter\Channel_#(channel number)_AGC_MaxGain			Example – Set maximum gain of AGC  <i>channel number – 3</i> <i>Value – 5</i>												
<b>Parameters :</b>  <table border="1"><thead><tr><th>Name</th><th>Values/range</th><th>Description</th></tr></thead><tbody><tr><td>channelnumber</td><td>1-12</td><td>channel number has to be replaced with actual input channel number</td></tr><tr><td>value</td><td>0 - 20</td><td></td></tr><tr><td>Format</td><td>Default</td><td>Format type</td></tr></tbody></table>			Name	Values/range	Description	channelnumber	1-12	channel number has to be replaced with actual input channel number	value	0 - 20		Format	Default	Format type	<b>Query/Command :</b>  set [{"path":"/Config/MatrixRouter/Channel_3_AGC_MaxGain", "value": "5", "format": "Default"}]  <b>Response :</b>  @set {"path":"/Config/MatrixRouter", "value": {"Channel_3_AGC_MaxGain": "5dB"}}
Name	Values/range	Description													
channelnumber	1-12	channel number has to be replaced with actual input channel number													
value	0 - 20														
Format	Default	Format type													

## 4.5. Set target level of AGC

<b>API :</b>  \Config\MatrixRouter\Channel_#(channel number)_AGC_TargetLevel	Example – Set target level of AGC  <i>channel number – 3</i> <i>Value – (-13)</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channelnumber</td> <td>1-12</td> <td>channel number has to be replaced with actual input channel number</td> </tr> <tr> <td>value</td> <td>(-30) - 0</td> <td></td> </tr> <tr> <td>Format</td> <td>Number</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	channelnumber	1-12	channel number has to be replaced with actual input channel number	value	(-30) - 0		Format	Number	Format type	<b>Query/Command :</b>  set [{"path":"/Config/MatrixRouter/Channel_3_AGC_TargetLevel","value":"-13","format":"Number"}]  <b>Response :</b>  @set {"format":"NUmber","path":"/Config/MatrixRouter/Channel_3_AGC_TargetLevel","value": "-13"}
Name	Values/range	Description											
channelnumber	1-12	channel number has to be replaced with actual input channel number											
value	(-30) - 0												
Format	Number	Format type											

## 4.6. Set Activation threshold value of AGC

<b>API :</b>  \Config\MatrixRouter\Channel_#(channel number)_AGC_ActivationThreshold	Example – Set activation threshold value of AGC  <i>channel number – 3</i> <i>Value – (-30)</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channelnumber</td> <td>1-12</td> <td>channel number has to be replaced with actual input channel number</td> </tr> <tr> <td>value</td> <td>(-60) – (-10)</td> <td></td> </tr> <tr> <td>Format</td> <td>Number</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	channelnumber	1-12	channel number has to be replaced with actual input channel number	value	(-60) – (-10)		Format	Number	Format type	<b>Query/Command :</b>  set [{"path":"/Config/MatrixRouter/Channel_3_AGC_ActivationThreshold","value":"-30","format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/MatrixRouter/Channel_3_AGC_ActivationThreshold","value": "-30"}
Name	Values/range	Description											
channelnumber	1-12	channel number has to be replaced with actual input channel number											
value	(-60) – (-10)												
Format	Number	Format type											

## 4.7. Set NLP strength value of AGC

<b>API :</b>  \Config\MatrixRouter\Channel_#(channel number)_TxNLPStrength	Example – Set activation threshold value of AGC  <i>channel number – 3</i> <i>Value – 70</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channelnumber</td> <td>1-12</td> <td>channel number has to be replaced with actual input channel number</td> </tr> <tr> <td>value</td> <td>0 - 80</td> <td></td> </tr> <tr> <td>Format</td> <td>Number</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	channelnumber	1-12	channel number has to be replaced with actual input channel number	value	0 - 80		Format	Number	Format type	<b>Query/Command :</b>  set [{"path":"/Config/MatrixRouter/Channel_3_TxNLPStrength","value":"70","format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/MatrixRouter/Channel_3_TxNLPStrength","value":"70"}
Name	Values/range	Description											
channelnumber	1-12	channel number has to be replaced with actual input channel number											
value	0 - 80												
Format	Number	Format type											

## 4.8. Get ERL value of AGC

<b>API :</b>  \Config\MatrixRouter\Channel_#(channel number)_ERL	Example – Get ERL value of channel 3  <i>channel number – 3</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channelnumber</td> <td>1-12</td> <td>channel number has to be replaced with actual input channel number</td> </tr> <tr> <td>value</td> <td>(-20) - 30</td> <td></td> </tr> <tr> <td>Format</td> <td>Norm</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	channelnumber	1-12	channel number has to be replaced with actual input channel number	value	(-20) - 30		Format	Norm	Format type	<b>Query/Command :</b>  get [{"path":"/Config/MatrixRouter/Channel_3_ERL","format":"Norm"}]  <b>Response :</b>  @get {"format":"Norm","path":"/Config/MatrixRouter/Channel_3_ERL","value":"0"}
Name	Values/range	Description											
channelnumber	1-12	channel number has to be replaced with actual input channel number											
value	(-20) - 30												
Format	Norm	Format type											

## 4.9. Get ERLE value of AGC

<b>API :</b>  \Config\MatrixRouter\Channel_#(channel number)_ERLE	Example – Get ERLE value of channel 3  <i>channel number – 3</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channelnumber</td> <td>1-12</td> <td>channel number has to be replaced with actual input channel number</td> </tr> <tr> <td>value</td> <td>(-20) - 30</td> <td></td> </tr> <tr> <td>Format</td> <td>Norm</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	channelnumber	1-12	channel number has to be replaced with actual input channel number	value	(-20) - 30		Format	Norm	Format type	<b>Query/Command :</b>  get [{"path":"/Config/MatrixRouter/Channel_3_ERLE","format":"Norm"}]  <b>Response :</b>  @get {"format":"Norm","path":"/Config/MatrixRouter/Channel_3_ERLE","value":"0 "}
Name	Values/range	Description											
channelnumber	1-12	channel number has to be replaced with actual input channel number											
value	(-20) - 30												
Format	Norm	Format type											

## 5. Automixer Screen

### 5.1. Set master gain

<b>API :</b>  /Config/MatrixRouter/AutoMixer_#(automixer number)_MasterGain	Example – Set master gain of Automixer 1 <i>automixer number – 1</i> <i>Value – 0.35</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>automixer number</td> <td>1-4</td> <td>automixer number has to be replaced with actual automixer number</td> </tr> <tr> <td>value</td> <td>(-80) - 10</td> <td></td> </tr> <tr> <td>Format</td> <td>Default</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	automixer number	1-4	automixer number has to be replaced with actual automixer number	value	(-80) - 10		Format	Default	Format type	<b>Query/Command :</b>  set [{"path":"/Config/MatrixRouter/AutoMixer_1_MasterGain","value":-35,"format":"Default"}]  <b>Response :</b>  @set {"format":"Default", "path":"/Config/MatrixRouter/AutoMixer_1_MasterGain","value":-35"}
Name	Values/range	Description											
automixer number	1-4	automixer number has to be replaced with actual automixer number											
value	(-80) - 10												
Format	Default	Format type											

### 5.2. Get master level

<b>API :</b>  /Config/PeakMeters/AutoMixer_#(automixer number)_MasterLevel	Example – Get Master level of Automixer 1(read only)  <i>automixer number – 1</i> <i>Value – 0.35</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>automixer number</td> <td>1-4</td> <td>automixer number has to be replaced with actual automixer number</td> </tr> <tr> <td>value</td> <td>(-80) - 10</td> <td>Range</td> </tr> <tr> <td>Format</td> <td>Number</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	automixer number	1-4	automixer number has to be replaced with actual automixer number	value	(-80) - 10	Range	Format	Number	Format type	<b>Query/Command :</b>  get [{"path":"/Config/PeakMeters/AutoMixer_1_MasterLevel","format":"Number"}]  <b>Response :</b>  @get {"format":"Number", "path":"/Config/PeakMeters/AutoMixer_1_MasterLevel","value":-80"}
Name	Values/range	Description											
automixer number	1-4	automixer number has to be replaced with actual automixer number											
value	(-80) - 10	Range											
Format	Number	Format type											

### 5.3. Mute master

<b>API :</b>  /Config/MatrixRouter/AutoMixer_#(automixer number)_MasterMute	Example – Enable Mute <i>automixer number – 1</i> <i>Value – 1</i>												
<b>Parameters :</b>  <table> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>automixer number</td> <td>1-4</td> <td>automixer number has to be replaced with actual automixer number</td> </tr> <tr> <td>value</td> <td>0-1</td> <td>on/off</td> </tr> <tr> <td>Format</td> <td>Norm</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	automixer number	1-4	automixer number has to be replaced with actual automixer number	value	0-1	on/off	Format	Norm	Format type	<b>Query/Command :</b>  set [{"path":"/Config/MatrixRouter/AutoMixer_1_MasterMute","value":1,"format":"Norm"}]  <b>Response :</b>  @set [{"path":"/Config/MatrixRouter/AutoMixer_1_MasterMute","value":1,"format":"Norm"}]
Name	Values/range	Description											
automixer number	1-4	automixer number has to be replaced with actual automixer number											
value	0-1	on/off											
Format	Norm	Format type											

### 5.4. Set Ratio (Slope)

<b>API :</b>  /Config/MatrixRouter/AutoMixer_#(automixer number)_Ratio	Example – Set ratio value <i>automixer number – 1</i> <i>value – 1.2</i>												
<b>Parameters :</b>  <table> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>automixer number</td> <td>1-4</td> <td>automixer number has to be replaced with actual automixer number</td> </tr> <tr> <td>value</td> <td>1-2</td> <td></td> </tr> <tr> <td>Format</td> <td>Number</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	automixer number	1-4	automixer number has to be replaced with actual automixer number	value	1-2		Format	Number	Format type	<b>Query/Command :</b>  set [{"path":"/Config/MatrixRouter/AutoMixer_1_Ratio","value":1.2,"format":"Number"}]  <b>Response :</b>  @set {"format":"Norm","path":"/Config/MatrixRouter/AutoMixer_1_Ratio","value":1.2}
Name	Values/range	Description											
automixer number	1-4	automixer number has to be replaced with actual automixer number											
value	1-2												
Format	Number	Format type											

## 5.5. Set Speed

<b>API :</b>  /Config/MatrixRouter/AutoMixer_#(automixer number)_Speed	Example – Set speed value <i>automixer number – 1</i> <i>Value – 1</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>automixer number</td> <td>1-4</td> <td>automixer number has to be replaced with actual automixer number</td> </tr> <tr> <td>value</td> <td>0.05 - 10</td> <td></td> </tr> <tr> <td>Format</td> <td>Number</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	automixer number	1-4	automixer number has to be replaced with actual automixer number	value	0.05 - 10		Format	Number	Format type	<b>Query/Command :</b>  set [{"path":"/Config/MatrixRouter/AutoMixer_1_Speed","value":0.58,"format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/MatrixRouter/AutoMixer_1_Speed","value":0.58}
Name	Values/range	Description											
automixer number	1-4	automixer number has to be replaced with actual automixer number											
value	0.05 - 10												
Format	Number	Format type											

## 5.6. Set Automixer Input gain

<b>API :</b>  /Config/MatrixRouter/Input_*(channel number)_AutoMixer_#(automixer number)_Gain	Example – Set gain of input channel 2 of automixer 1  <i>channel number - 2</i> <i>automixer number – 1</i> <i>value – .44</i>															
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>1-12</td> <td>channel number has to be replaced with actual input channel number</td> </tr> <tr> <td>automixer number</td> <td>1-4</td> <td>automixer number has to be replaced with actual automixer number</td> </tr> <tr> <td>value</td> <td></td> <td></td> </tr> <tr> <td>Format</td> <td>Norm</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	channel number	1-12	channel number has to be replaced with actual input channel number	automixer number	1-4	automixer number has to be replaced with actual automixer number	value			Format	Norm	Format type	<b>Query/Command :</b>  set [{"path":"/Config/MatrixRouter/Input_2_AutoMixer_1_Gain","value":0.44,"format":"Norm"}]  <b>Response :</b>  @set {"format":"Norm","path":"/Config/MatrixRouter/Input_2_AutoMixer_1_Gain","value":0.44}
Name	Values/range	Description														
channel number	1-12	channel number has to be replaced with actual input channel number														
automixer number	1-4	automixer number has to be replaced with actual automixer number														
value																
Format	Norm	Format type														

## 5.7. Mute Input channel of Automixer

<b>API :</b>  /Config/MatrixRouter/Input_*(channel number)_AutoMixer_#(automixer number)_Mute			Example – Mute input channel 2 of Automixer 1 <i>Channel number - 2</i> <i>automixer number – 1</i> <i>Value – 1</i>															
<b>Parameters :</b>			<b>Query/Command :</b>															
<table border="1"> <thead> <tr> <th>Name</th><th>Values/range</th><th>Description</th></tr> </thead> <tbody> <tr> <td>channel number</td><td>1-12</td><td>channel number has to be replaced with actual input channel number</td></tr> <tr> <td>automixer number</td><td>1-4</td><td>automixer number has to be replaced with actual automixer number</td></tr> <tr> <td>value</td><td>0-1</td><td>Mute/Unmute</td></tr> <tr> <td>Format</td><td>Norm</td><td>Format type</td></tr> </tbody> </table>			Name	Values/range	Description	channel number	1-12	channel number has to be replaced with actual input channel number	automixer number	1-4	automixer number has to be replaced with actual automixer number	value	0-1	Mute/Unmute	Format	Norm	Format type	<pre>set [{"path":"/Config/MatrixRouter/Input_2_AutoMixer_1_Mute","value":1,"format":"Norm"}]</pre> <b>Response :</b> <pre>@set {"format":"Norm","path":"/Config/MatrixRouter/Input_2_AutoMixer_1_Mute","value":1}</pre>
Name	Values/range	Description																
channel number	1-12	channel number has to be replaced with actual input channel number																
automixer number	1-4	automixer number has to be replaced with actual automixer number																
value	0-1	Mute/Unmute																
Format	Norm	Format type																

## 5.8. Set Input channel OffGain of Automixer

<b>API :</b>  /Config/MatrixRouter/Input_*(channel number)_AutoMixer_#(automixer number)_OffGain			Example – Set OffGain of Automixer 1 of Input channel 1  Channel number – 1 Automixer number - 1															
<b>Parameters :</b>			<b>Query/Command :</b>															
<table border="1"> <thead> <tr> <th>Name</th><th>Values/range</th><th>Description</th></tr> </thead> <tbody> <tr> <td>channel number</td><td>1-12</td><td>channel number has to be replaced with actual input channel number</td></tr> <tr> <td>automixer number</td><td>1-4</td><td>automixer number has to be replaced with actual automixer number</td></tr> <tr> <td>value</td><td>(-40) – 0</td><td></td></tr> <tr> <td>Format</td><td>Number</td><td></td></tr> </tbody> </table>			Name	Values/range	Description	channel number	1-12	channel number has to be replaced with actual input channel number	automixer number	1-4	automixer number has to be replaced with actual automixer number	value	(-40) – 0		Format	Number		<pre>set [{"path":"/Config/MatrixRouter/Input_1_AutoMixer_1_OffGain","value":0,"format":"Number"}]</pre> <b>Response :</b> <pre>@set {"format":"Number","path":"/Config/MatrixRouter/Input_1_AutoMixer_1_OffGain","value":0}</pre>
Name	Values/range	Description																
channel number	1-12	channel number has to be replaced with actual input channel number																
automixer number	1-4	automixer number has to be replaced with actual automixer number																
value	(-40) – 0																	
Format	Number																	

## 5.9. Get Input channel OpenMeter of Automixer

<b>API :</b>	Example –	
/Config/MatrixRouter/Input_*(channel number)_AutoMixer_#(automixer number)_OpenMeter		
<b>Parameters :</b>	<b>Query/Command :</b>	
Name	Values/range	Description
channel number	1-12	channel number has to be replaced with actual input channel number
automixer number	1-4	automixer number has to be replaced with actual automixer number
value	0-1	
Format	Norm	

## 5.10. Set Input channel Override of Automixer

<b>API :</b>  /Config/MatrixRouter/Input_*(channel number)_AutoMixer_#(automixer number)_Override			Example – Enable override of input channel 1 of automixer 1  <i>Channel number – 1</i> <i>Automixer number -1</i> <i>Value - 1</i>															
<b>Parameters :</b> <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>1-12</td> <td>channel number has to be replaced with actual input channel number</td> </tr> <tr> <td>automixer number</td> <td>1-4</td> <td>automixer number has to be replaced with actual automixer number</td> </tr> <tr> <td>value</td> <td>0-1</td> <td></td> </tr> <tr> <td>Format</td> <td>Norm</td> <td>Format type</td> </tr> </tbody> </table>			Name	Values/range	Description	channel number	1-12	channel number has to be replaced with actual input channel number	automixer number	1-4	automixer number has to be replaced with actual automixer number	value	0-1		Format	Norm	Format type	<b>Query/Command :</b>  set [{"path":"/Config/MatrixRouter/Input_1_AutoMixer_1.Override","value":1,"format":"Norm"}]
Name	Values/range	Description																
channel number	1-12	channel number has to be replaced with actual input channel number																
automixer number	1-4	automixer number has to be replaced with actual automixer number																
value	0-1																	
Format	Norm	Format type																

**Response :**

```
@set
{"format":"Norm","path":"/Config/MatrixRouter/Input_1_AutoMixer_1.Override","value":"1"}
```

## 5.11. Set Solo in Automixer

<b>API :</b>  /Config/MatrixRouter/Input_*(channel number)_AutoMixer_#(automixer number)_Solo			Example – Activate Solo of input channel 2 of automixer 1  <i>Channel number – 2</i> <i>Automixer number -1</i> <i>Value - 1</i>															
<b>Parameters :</b> <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>1-12</td> <td>channel number has to be replaced with actual input channel number</td> </tr> <tr> <td>automixer number</td> <td>1-4</td> <td>automixer number has to be replaced with actual automixer number</td> </tr> <tr> <td>value</td> <td>0-1</td> <td></td> </tr> <tr> <td>Format</td> <td>Norm</td> <td>Format type</td> </tr> </tbody> </table>			Name	Values/range	Description	channel number	1-12	channel number has to be replaced with actual input channel number	automixer number	1-4	automixer number has to be replaced with actual automixer number	value	0-1		Format	Norm	Format type	<b>Query/Command :</b>  set [{"path":"/Config/MatrixRouter/Input_2_AutoMixer_1.Solo","value":1,"format":"Norm"}]
Name	Values/range	Description																
channel number	1-12	channel number has to be replaced with actual input channel number																
automixer number	1-4	automixer number has to be replaced with actual automixer number																
value	0-1																	
Format	Norm	Format type																

**Response :**

```
@set
{"format":"Norm","path":"/Config/MatrixRouter/Input_2_AutoMixer_1.Solo","value":"1"}
```

## 5.12. Set Automixer Input Connection

<b>API :</b>  /Config/MatrixRouter/Automixer_#(automixer number)_Input_*(channel number)_Connection			Example – Select Input channel 2 to Automixer 1  Channel number – 2 Automixer number - 1
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	
channel number	1-12	channel number has to be replaced with actual input channel number	set [{"path":"/Config/MatrixRouter/Automixer_1_Input_2_Connection","value":1,"format":"Norm"}]
automixer number	1-4	automixer number has to be replaced with actual automixer number	<b>Response :</b>  @set {"format":"Norm","path":"/Config/MatrixRouter/Automixer_1_Input_2_Connection","value":1"}
value	0-1		
Format	Norm	Format type	

## 5.13. Set Automixer Output Connection

<b>API :</b>  /Config/MatrixRouter/Automixer_#(automixer number)_Output_*(channel number)_Connection			Example – Select Input channel 2 to Automixer 1  Channel number – 2 Automixer number - 1
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	
channel number	1-12	channel number has to be replaced with actual input channel number	set [{"path":"/Config/MatrixRouter/Automixer_1_Output_2_Connection","value":1,"format":"Norm"}]
automixer number	1-4	automixer number has to be replaced with actual automixer number	<b>Response :</b>  @set {"format":"Norm","path":"/Config/MatrixRouter/Automixer_1_Output_2_Connection","value":1"}
value	0-1		
Format	Norm	Format type	

## 5.14. Set Automixer (1-4) name

<b>API :</b>	Example – Set name of Automixer 1 as "Meeting1"  <i>Value – Meeting1</i>
/Config/MatrixRouter/Room_1_Name  /Config/MatrixRouter/Room_2_Name  /Config/MatrixRouter/Room_3_Name  /Config/MatrixRouter/Room_4_Name	
<b>Parameters :</b>	<p><b>Query/Command :</b></p> <pre>set [{"path":"/Config/MatrixRouter/Room_1_Name ","value":"Conference1","format":"Default"}]</pre> <p><b>Response :</b></p> <pre>@set {"path":"/Config/MatrixRouter","value":{"Room _1_Name":"Conference1"}}</pre>

## 6. Control Compressor parameters

### 6.1. Set Bypass value

<b>API :</b>  /Config/Channel##(channel number)Compressor/Bypass	Example – Set Bypass value of channel 14  Channel number – 14 Value - 0												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>13-28</td> <td>Channel number has to be replaced by actual input channel number</td> </tr> <tr> <td>value</td> <td>0-1</td> <td>On/Off</td> </tr> <tr> <td>Format</td> <td>Norm</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	Channel number	13-28	Channel number has to be replaced by actual input channel number	value	0-1	On/Off	Format	Norm	Format type	<b>Query/Command :</b>  set [{"path":"/Config/Channel14Compressor/Bypass","value":0,"format":"Norm"}]  <b>Response :</b>  @set {"format":"Norm","path":"/Config/Channel14Compressor/Bypass","value":"0"}
Name	Values/range	Description											
Channel number	13-28	Channel number has to be replaced by actual input channel number											
value	0-1	On/Off											
Format	Norm	Format type											

### 6.2. Set Threshold value

<b>API :</b>  /Config/Channel#(channel number)Compressor/Threshold	Example – Set threshold value of input channel 15  <i>Channel number – 15</i> <i>Value – 6</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>13 -28</td> <td>Channel number has to be replaced by actual input channel number</td> </tr> <tr> <td>value</td> <td>(-120) - 20</td> <td>Value to be set</td> </tr> <tr> <td>Format</td> <td>Number</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	Channel number	13 -28	Channel number has to be replaced by actual input channel number	value	(-120) - 20	Value to be set	Format	Number	Format type	<b>Query/Command :</b>  set [{"path":"/Config/Channel15Compressor/Threshold","value":6,"format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/Channel15Compressor/Threshold","value":6}
Name	Values/range	Description											
Channel number	13 -28	Channel number has to be replaced by actual input channel number											
value	(-120) - 20	Value to be set											
Format	Number	Format type											

### 6.3. Set Ratio value

<b>API :</b>  /Config/Channel#(channel number)Compressor/Ratio	Example – Set Ratio value of input channel 15  <i>Channel number – 15</i> <i>Value – 5</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>13 -28</td> <td>Channel number has to be replaced by actual input channel number</td> </tr> <tr> <td>value</td> <td>1 -18</td> <td>Value to be set</td> </tr> <tr> <td>Format</td> <td>Norm</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	Channel number	13 -28	Channel number has to be replaced by actual input channel number	value	1 -18	Value to be set	Format	Norm	Format type	<b>Query/Command :</b>  set [{"path":"/Config/Channel15Compressor/Ratio", "value":5,"format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/Channel15Compressor/Ratio","value":"5"}
Name	Values/range	Description											
Channel number	13 -28	Channel number has to be replaced by actual input channel number											
value	1 -18	Value to be set											
Format	Norm	Format type											

### 6.4. Set Gain value

<b>API :</b>  /Config/Channel#(channel number)Compressor/Gain	Example – Set Gain value of input channel 15  <i>Channel number – 15</i> <i>Value – 19</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>13 -28</td> <td>Channel number has to be replaced by actual input channel number</td> </tr> <tr> <td>value</td> <td>(-20) - 20</td> <td>Value to be set</td> </tr> <tr> <td>Format</td> <td>Number</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	Channel number	13 -28	Channel number has to be replaced by actual input channel number	value	(-20) - 20	Value to be set	Format	Number	Format type	<b>Query/Command :</b>  set [{"path":"/Config/Channel15Compressor/Gain", "value":19,"format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/Channel15Compressor/Gain","value":"19"}
Name	Values/range	Description											
Channel number	13 -28	Channel number has to be replaced by actual input channel number											
value	(-20) - 20	Value to be set											
Format	Number	Format type											

## 6.5. Get GainReduction value

<b>API :</b>  /Config/Channel#(channel number)Compressor/GainReduction			Example – Read GainReduction of channel 14 (read only)  Channel number - 14
<b>Parameters :</b>			<b>Query/Command :</b>
<b>Name</b>	<b>Values/range</b>	<b>Description</b>	<pre>get [{"path":"/Config/Channel14Compressor/GainReduction","format":"Number"}]</pre> <b>Response :</b> <pre>@get {"format":"Number","path":"/Config/Channel14Compressor/GainReduction","value":"0"}</pre>

## 6.6. Get InputLevel value

<b>API :</b>  /Config/Channel#(channel number)Compressor/InputLevel			Example – Read InputLevel of channel 14 (read only)  Channel number - 14
<b>Parameters :</b>			<b>Query/Command :</b>
<b>Name</b>	<b>Values/range</b>	<b>Description</b>	<pre>get [{"path":"/Config/Channel14Compressor/InputLevel","format":"Number"}]</pre> <b>Response :</b> <pre>@get {"format":"Number","path":"/Config/Channel14Compressor/InputLevel","value":"0"}</pre>

## 6.7. Set Attack value

<b>API :</b>  /Config/Channel#(channel number)Compressor/Attack	Example – Set Attack value of Input channel 14  <i>Channel number – 14</i> <i>Value - 21</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>13 -28</td> <td>Channel number has to be replaced by actual input channel number</td> </tr> <tr> <td>value</td> <td>0-200</td> <td>Value to be set</td> </tr> <tr> <td>Format</td> <td>Number</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	Channel number	13 -28	Channel number has to be replaced by actual input channel number	value	0-200	Value to be set	Format	Number	Format type	<b>Query/Command :</b>  set [{"path":"/Config/Channel14Compressor/Attack","value":"21","format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/Channel14Compressor/Attack","value":"21"}
Name	Values/range	Description											
Channel number	13 -28	Channel number has to be replaced by actual input channel number											
value	0-200	Value to be set											
Format	Number	Format type											

## 6.8. Set Release value

<b>API :</b>  /Config/Channel#(channel number)Compressor/Release	Example – Set Release value of input channel 14  Channel number – 14 Value - 1999												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>13 -28</td> <td>Channel number has to be replaced by actual input channel number</td> </tr> <tr> <td>value</td> <td>5-2000</td> <td>Value to be set</td> </tr> <tr> <td>Format</td> <td>Number</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	Channel number	13 -28	Channel number has to be replaced by actual input channel number	value	5-2000	Value to be set	Format	Number	Format type	<b>Query/Command :</b>  set [{"path":"/Config/Channel14Compressor/Release","value":"1999","format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/Channel14Compressor/Release","value":"1999"}
Name	Values/range	Description											
Channel number	13 -28	Channel number has to be replaced by actual input channel number											
value	5-2000	Value to be set											
Format	Number	Format type											

## 7. Control Limiter parameters

### 7.1. Set Bypass value

<b>API :</b>  /Config/Output#(channel number)Limiter/Bypass	Example – Disable Bypass of Output channel 1  Channel number – 1 Value - 0												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>1-12</td> <td>Channel number has to be replaced by actual input channel number</td> </tr> <tr> <td>value</td> <td>0-1</td> <td>0 – enable 1- Disable</td> </tr> <tr> <td>Format</td> <td>Norm</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	channel number	1-12	Channel number has to be replaced by actual input channel number	value	0-1	0 – enable 1- Disable	Format	Norm	Format type	<b>Query/Command :</b>  set [{"path":"/Config/Output1Limiter/Bypass","value":1,"format":"Norm"}]  <b>Response :</b>  @set {"format":"Norm","path":"/Config/Output1Limiter/Bypass","value":1}
Name	Values/range	Description											
channel number	1-12	Channel number has to be replaced by actual input channel number											
value	0-1	0 – enable 1- Disable											
Format	Norm	Format type											

### 7.2. Set Threshold value

<b>API :</b>  /Config/Output#(channel number)Limiter/Threshold	Example – Set threshold value of output channel 1  <i>Channel number – 11</i> <i>Value – 1</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-12</td> <td>Channel number has to be replaced by actual output channel number</td> </tr> <tr> <td>value</td> <td>(-120) - 20</td> <td>Value to be set</td> </tr> <tr> <td>Format</td> <td>Number</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	Channel number	1-12	Channel number has to be replaced by actual output channel number	value	(-120) - 20	Value to be set	Format	Number	Format type	<b>Query/Command :</b>  set [{"path":"/Config/Output1Limiter/Threshold","value":1,"format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/Output1Limiter/Threshold","value":1}
Name	Values/range	Description											
Channel number	1-12	Channel number has to be replaced by actual output channel number											
value	(-120) - 20	Value to be set											
Format	Number	Format type											

### 7.3. Get GainReduction value

<b>API :</b> <pre>/Config/Output#(channel number)Limiter/GainReduction</pre>			Example – Read GainReduction of Output channel 1  Channel number – 1												
<b>Parameters :</b> <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-12</td> <td>Channel number has to be replaced by actual output channel number</td> </tr> <tr> <td>value</td> <td>0 - 120</td> <td>Value to be set</td> </tr> <tr> <td>Format</td> <td>Number</td> <td>Format type</td> </tr> </tbody> </table>			Name	Values/range	Description	Channel number	1-12	Channel number has to be replaced by actual output channel number	value	0 - 120	Value to be set	Format	Number	Format type	<b>Query/Command :</b> <pre>get [{"path":"/Config/Output1Limiter/GainReduction","format":"Number"}]</pre> <b>Response :</b> <pre>@get {"format":"Number","path":"/Config/Output1Limiter/GainReduction","value":"0"}</pre>
Name	Values/range	Description													
Channel number	1-12	Channel number has to be replaced by actual output channel number													
value	0 - 120	Value to be set													
Format	Number	Format type													

### 7.4. Get InputLevel value

<b>API :</b> <pre>/Config/Output#(channel number)Limiter/InputLevel</pre>			Example – Read InputLevel of Output channel 1  Channel number - 1												
<b>Parameters :</b> <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-12</td> <td>Channel number has to be replaced by actual output channel number</td> </tr> <tr> <td>value</td> <td>(-120) - 20</td> <td>Value to be set</td> </tr> <tr> <td>Format</td> <td>Number</td> <td>Format type</td> </tr> </tbody> </table>			Name	Values/range	Description	Channel number	1-12	Channel number has to be replaced by actual output channel number	value	(-120) - 20	Value to be set	Format	Number	Format type	<b>Query/Command :</b> <pre>get [{"path":"/Config/Output1Limiter/InputLevel","format":"Number"}]</pre> <b>Response :</b> <pre>@get {"format":"Number","path":"/Config/Output1Limiter/InputLevel","value":"20"}</pre>
Name	Values/range	Description													
Channel number	1-12	Channel number has to be replaced by actual output channel number													
value	(-120) - 20	Value to be set													
Format	Number	Format type													

## 7.5. Set Attack value

<b>API :</b>  /Config/Output#(channel number)Limiter/Attack			Example – Set Attack value  Channel number – 3 Value - 999 ( 999 ms)												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-12</td> <td>Channel number has to be replaced by actual output channel number</td> </tr> <tr> <td>value</td> <td>0 - 1000</td> <td>Display in millisecond (0 ms -1000 ms)</td> </tr> <tr> <td>Format</td> <td>Number</td> <td>Format type</td> </tr> </tbody> </table>			Name	Values/range	Description	Channel number	1-12	Channel number has to be replaced by actual output channel number	value	0 - 1000	Display in millisecond (0 ms -1000 ms)	Format	Number	Format type	<b>Query/Command :</b>  set [{"path":"/Config/Output3Limiter/Attack","value":999,"format":"Number"}]
Name	Values/range	Description													
Channel number	1-12	Channel number has to be replaced by actual output channel number													
value	0 - 1000	Display in millisecond (0 ms -1000 ms)													
Format	Number	Format type													

**Response :**

```
@set
{"format":"Number","path":"/Config/Output3Limiter/Attack","value":999}
```

## 7.6. Set Release value

<b>API :</b>  /Config/Output#(channel number)Limiter/Release			Example – Set Release value  Channel number – 3 Value - 999 ( 999 ms)												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-12</td> <td>Channel number has to be replaced by actual output channel number</td> </tr> <tr> <td>value</td> <td>0 – 1000</td> <td>Display in millisecond (0 ms -1000 ms)</td> </tr> <tr> <td>Format</td> <td>Number</td> <td>Format type</td> </tr> </tbody> </table>			Name	Values/range	Description	Channel number	1-12	Channel number has to be replaced by actual output channel number	value	0 – 1000	Display in millisecond (0 ms -1000 ms)	Format	Number	Format type	<b>Query/Command :</b>  set [{"path":"/Config/Output3Limiter/Release","value":999,"format":"Number"}]
Name	Values/range	Description													
Channel number	1-12	Channel number has to be replaced by actual output channel number													
value	0 – 1000	Display in millisecond (0 ms -1000 ms)													
Format	Number	Format type													

**Response :**

```
@set
{"format":"Number","path":"/Config/Output3Limiter/Release","value":999}
```

## 8. Configure channel – AES67

### 8.1. Set Frame Rate

<b>API :</b>  \Config\Channel#(channel number)Delay \FrameRate	Example – Set Frame rate of channel 3  Channel number – 3 Value – 24 FPS												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>1-28</td> <td>Channel number has to be replaced by actual input channel number</td> </tr> <tr> <td>value</td> <td>24 FPS 30 FPS 60 FPS</td> <td></td> </tr> <tr> <td>Format</td> <td>Default</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	channel number	1-28	Channel number has to be replaced by actual input channel number	value	24 FPS 30 FPS 60 FPS		Format	Default	Format type	<b>Query/Command :</b>  set [{"path":"/Config/Channel3Delay/FrameRate","value":"24 FPS","format":"Default"}]  <b>Response :</b>  @set {"path":"/Config/Channel3Delay","value":{"FrameRate":"24 FPS"}}
Name	Values/range	Description											
channel number	1-28	Channel number has to be replaced by actual input channel number											
value	24 FPS 30 FPS 60 FPS												
Format	Default	Format type											

### 8.2. Set DelayTime

<b>API :</b>  \Config\Channel#(channel number)Delay\DelayTime	Example – Set Delaytime of channel 3  Channel number – 3 Value - 0												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>1-28</td> <td>Channel number has to be replaced by actual input channel number</td> </tr> <tr> <td>value</td> <td>0 - 300</td> <td></td> </tr> <tr> <td>Format</td> <td>Number</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	channel number	1-28	Channel number has to be replaced by actual input channel number	value	0 - 300		Format	Number	Format type	<b>Query/Command :</b>  set [{"path":"/Config/Channel3Delay/DelayTime","value":0,"format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/Channel3Delay/DelayTime","value":"0"}
Name	Values/range	Description											
channel number	1-28	Channel number has to be replaced by actual input channel number											
value	0 - 300												
Format	Number	Format type											

### 8.3. Set Processing

<b>API :</b>  \Config\Channel#(channel number)\Processing	Example – Set processing  Channel number – 3 Value - 0												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>1-28</td> <td>Channel number has to be replaced by actual input channel number</td> </tr> <tr> <td>value</td> <td>0 - 1</td> <td></td> </tr> <tr> <td>Format</td> <td>Number</td> <td>Format type</td> </tr> </tbody> </table>	Name	Values/range	Description	channel number	1-28	Channel number has to be replaced by actual input channel number	value	0 - 1		Format	Number	Format type	<b>Query/Command :</b>  set [{"path":"/Config/Channel3Delay/Processing","value":0,"format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/Channel3Delay/Processing","value":"1"}
Name	Values/range	Description											
channel number	1-28	Channel number has to be replaced by actual input channel number											
value	0 - 1												
Format	Number	Format type											

## 9. Schematic Screen

### 9.1. Get meter data of input channel before processing

<b>API :</b>  /Config/PeakMeters/In#(channel number)InputLevel			Example – Get meter data of Input channel 13  <i>Channel number - 13</i>												
<b>Parameters :</b>			<b>Query/Command :</b>												
<table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>1-28</td> <td>channel number need to be replaced with corresponding input channel number</td> </tr> <tr> <td>Format</td> <td>Number</td> <td></td> </tr> <tr> <td>Value</td> <td>(-80) - 20</td> <td>Value ranging -80 to 20db</td> </tr> </tbody> </table>			Name	Values/range	Description	channel number	1-28	channel number need to be replaced with corresponding input channel number	Format	Number		Value	(-80) - 20	Value ranging -80 to 20db	<b>get</b> [{"path":"/Config/PeakMeters/In13InputLevel", "format": "Number"}]  <b>Response :</b>  @get {"format":"Number", "path": "/Config/PeakMeters/In13InputLevel", "value": "-2"}
Name	Values/range	Description													
channel number	1-28	channel number need to be replaced with corresponding input channel number													
Format	Number														
Value	(-80) - 20	Value ranging -80 to 20db													

### 9.2. Get meter data of input channel after processing

<b>API :</b>  /Config/PeakMeters/In#(channel number)OutputLevel			Example – Get meter data of Input channel 13  <i>Channel number - 13</i>												
<b>Parameters :</b>			<b>Query/Command :</b>												
<table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>1-28</td> <td>channel number need to be replaced with corresponding input channel number</td> </tr> <tr> <td>Format</td> <td>Number</td> <td></td> </tr> <tr> <td>Value</td> <td>(-80) - 20</td> <td>Value ranging -80 to 20db</td> </tr> </tbody> </table>			Name	Values/range	Description	channel number	1-28	channel number need to be replaced with corresponding input channel number	Format	Number		Value	(-80) - 20	Value ranging -80 to 20db	<b>get</b> [{"path":"/Config/PeakMeters/In13OutputLevel", "format": "Number"}]  <b>Response :</b>  @get {"format":"Number", "path": "/Config/PeakMeters/In13OutputLevel", "value": "-2"}
Name	Values/range	Description													
channel number	1-28	channel number need to be replaced with corresponding input channel number													
Format	Number														
Value	(-80) - 20	Value ranging -80 to 20db													

### 9.3. Set Mute/Unmute of Input channel

<b>API :</b>  \Config\Channel#(channel number)Level\Mute			Example – Set mute of input channel 2  <i>Channel number - 2</i>
<b>Parameters :</b>			<b>Query/Command :</b>
<b>Name</b>	<b>Values/range</b>	<b>Description</b>	<p><b>set</b> [{"path":"/Config/Channel2Level/Mute","value":1,"format":"Norm"}]</p> <p><b>Response :</b></p> <pre>@set {"format":"Norm","path":"/Config/Channel1Leve l/Mute","value":1}</pre>

### 9.4. Set level of Input channel

<b>API :</b>  \Config\Channel#(channel number)Level\Level			Example – Set level of input channel 2  <i>Channel number – 2</i> <i>Value – 0.68</i>
<b>Parameters :</b>			<b>Query/Command :</b>
<b>Name</b>	<b>Values/range</b>	<b>Description</b>	<p><b>set</b> [{"path":"/Config/Channel1Level/Level","value":0.68,"format":"Norm"}]</p> <p><b>set</b> [{"path":"/Config/Channel1Level/Level","value":20,"format":"Default"}]</p> <p><b>Response :</b></p> <pre>@set {"format":"Norm","path":"/Config/Channel1Leve l/Level","value":0.68} @set {"format":"Default","path":"/Config/Channel1Lev el/Level","value":20}</pre>

## 9.5. Enable PEQ of Input channel

<b>API :</b>  Config\Channel#(channel number)PEQ\ParametricEQ	Example – Enable PEQ of channel 1  <i>Channel number – 1</i> <i>Value - 1</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>1-28</td> <td>channel number need to be replaced with corresponding input channel number</td> </tr> <tr> <td>Format</td> <td>Norm</td> <td></td> </tr> <tr> <td>Value</td> <td>0-1</td> <td>0 – Disable 1 - enable</td> </tr> </tbody> </table>	Name	Values/range	Description	channel number	1-28	channel number need to be replaced with corresponding input channel number	Format	Norm		Value	0-1	0 – Disable 1 - enable	<b>Query/Command :</b>  set [{"path":"/Config/Channel1PEQ/ParametricEQ","value":1,"format":"Norm"}]  <b>Response :</b>  @set {"format":"Norm","path":"/Config/Channel1PEQ/ParametricEQ","value":"1"}
Name	Values/range	Description											
channel number	1-28	channel number need to be replaced with corresponding input channel number											
Format	Norm												
Value	0-1	0 – Disable 1 - enable											

## 9.6. Enable Bypass (Compressor) of Input channel

<b>API :</b>  \Config\Channel#(channel number)Compressor\Bypass	Example – Enable Compressor of channel 14  Channel number – 14 Value - 0												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>1-28</td> <td>channel number need to be replaced with corresponding input channel number</td> </tr> <tr> <td>Format</td> <td>Norm</td> <td></td> </tr> <tr> <td>Value</td> <td>0-1</td> <td>0 – Enable 1-Disable</td> </tr> </tbody> </table>	Name	Values/range	Description	channel number	1-28	channel number need to be replaced with corresponding input channel number	Format	Norm		Value	0-1	0 – Enable 1-Disable	<b>Query/Command :</b>  set [{"path":"/Config/Channel14Compressor/Bypass","value":0,"format":"Norm"}]  <b>Response :</b>  @set {"format":"Norm","path":"/Config/Channel14Compressor/Bypass","value":"0"}
Name	Values/range	Description											
channel number	1-28	channel number need to be replaced with corresponding input channel number											
Format	Norm												
Value	0-1	0 – Enable 1-Disable											

## 9.7. Get meter data of output channel before processing

<b>API :</b>  /Config/PeakMeters/Out#(channel number)InputLevel			Example – Get meter data of Output channel 1  <i>Channel number - 1</i>											
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>1-12</td> <td>channel number need to be replaced with corresponding input channel number</td> </tr> <tr> <td>Format</td> <td>Number</td> <td></td> </tr> <tr> <td>Value</td> <td>(-80) - 20</td> <td>Value ranging -80 to 20db</td> </tr> </tbody> </table>			Name	Values/range	Description	channel number	1-12	channel number need to be replaced with corresponding input channel number	Format	Number		Value	(-80) - 20	Value ranging -80 to 20db
Name	Values/range	Description												
channel number	1-12	channel number need to be replaced with corresponding input channel number												
Format	Number													
Value	(-80) - 20	Value ranging -80 to 20db												

## 9.8. Get meter data of output channel after processing

<b>API :</b>  /Config/PeakMeters/Out#(channel number)OutputLevel			Example – Get meter data of Output channel 1  <i>Channel number - 1</i>											
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>1-28</td> <td>channel number need to be replaced with corresponding input channel number</td> </tr> <tr> <td>Format</td> <td>Number</td> <td></td> </tr> <tr> <td>Value</td> <td>(-80) - 20</td> <td>Value ranging -80 to 20db</td> </tr> </tbody> </table>			Name	Values/range	Description	channel number	1-28	channel number need to be replaced with corresponding input channel number	Format	Number		Value	(-80) - 20	Value ranging -80 to 20db
Name	Values/range	Description												
channel number	1-28	channel number need to be replaced with corresponding input channel number												
Format	Number													
Value	(-80) - 20	Value ranging -80 to 20db												

## 9.9. Set Mute/Unmute of output channel

<b>API :</b> \Config\Output#(channel number)Level\Mute			Example – Set Unmute of output channel 1  <i>Channel number – 1</i> <i>Value - 0</i>
<b>Parameters :</b>			<b>Query/Command :</b>
<b>Name</b>	<b>Values/range</b>	<b>Description</b>	<p><b>set</b> [{"path":"/Config/Output1Level/Mute","value":0,"format":"Norm"}]</p> <p><b>Response :</b></p> <pre>@set {"format":"Norm","path":"/Config/Output1Level /Mute","value":"0"}</pre>

## 9.10. Set level (Gain) of output channel

<b>API :</b> \Config\Output#(channel number)Level\Gain			Example – Set level of output channel 1  <i>Channel number – 1</i> <i>Value – 0.97</i>
<b>Parameters :</b>			<b>Query/Command :</b>
<b>Name</b>	<b>Values/range</b>	<b>Description</b>	<p><b>set set</b> [{"path":"/Config/Output1Level/Gain","value":0,"format":"Default"}]</p> <p><b>Response :</b></p> <pre>@set {"format":"Default","path":"/Config/Output1Lev el/Gain","value":"0"}</pre>

## 9.11. Enable PEQ of Input channel

<b>API :</b>  Config\Channel#(channel number)PEQ\ParametricEQ	Example – Enable PEQ of Input channel 1  <i>Channel number – 1</i> <i>Value - 1</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>1-28</td> <td>channel number need to be replaced with corresponding input channel number</td> </tr> <tr> <td>Format</td> <td>Norm</td> <td></td> </tr> <tr> <td>Value</td> <td>0-1</td> <td>0-Disable 1-Enable</td> </tr> </tbody> </table>	Name	Values/range	Description	channel number	1-28	channel number need to be replaced with corresponding input channel number	Format	Norm		Value	0-1	0-Disable 1-Enable	<b>Query/Command :</b>  set [{"path":"/Config/Channel1PEQ/ParametricEQ","value":1,"format":"Norm"}]  <b>Response :</b>  @set {"format":"Norm","path":"/Config/Channel1PEQ/ParametricEQ","value":1}
Name	Values/range	Description											
channel number	1-28	channel number need to be replaced with corresponding input channel number											
Format	Norm												
Value	0-1	0-Disable 1-Enable											

## 9.12. Enable Bypass (Compressor) of Input channel

<b>API :</b>  \Config\Channel#(channel number)Compressor\Bypass	Example – Enable Bypass (compressor) of Input channel 14  <i>Channel number – 14</i> <i>Value - 1</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>14-28</td> <td>channel number need to be replaced with corresponding input channel number</td> </tr> <tr> <td>Format</td> <td>Norm</td> <td></td> </tr> <tr> <td>Value</td> <td>0-1</td> <td>0-Disable 1-Enable</td> </tr> </tbody> </table>	Name	Values/range	Description	channel number	14-28	channel number need to be replaced with corresponding input channel number	Format	Norm		Value	0-1	0-Disable 1-Enable	<b>Query/Command :</b>  set [{"path":"/Config/Channel14Compressor/Bypass","value":1,"format":"Norm"}]  <b>Response :</b>  @set {"format":"Norm","path":"/Config/Channel14Compressor/Bypass","value":1}
Name	Values/range	Description											
channel number	14-28	channel number need to be replaced with corresponding input channel number											
Format	Norm												
Value	0-1	0-Disable 1-Enable											

## 10. PEQ Screen

### 10.1. Set HPFrequency of Input channel

<b>API :</b>  \Config\Channel#(channel number)HighPass\Channel_1_HPFrequency			Example – Set HPFrequency of input channel 2  <i>Channel number – 2</i> <i>Value - 60</i>
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	
channel number	1-28	channel number need to be replaced with corresponding input channel number	set [{"path":"/Config/Channel2HighPass/Channel_1_HPFrequency","value":60,"format":"Number"}]
Format	Number		<b>Response :</b>  @set {"format":"Number","path":"/Config/Channel2HighPass/Channel_1_HPFrequency","value":"60"}
Value	15.9 - 20000		

### 10.2. Set HPType of Input channel

<b>API :</b>  \Config\Channel#(channel number)HighPass\Channel_1_HPType			Example –
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	<b>Response :</b>
channel number	1-28	channel number need to be replaced with corresponding input channel number	
Format	Number		
Value	BS 6 - LR 24	( BS 6 BS 12 BS 18 BS 24 BW 6 BW 12 BW 18 BW 24	

		LR 12 LR 24 )	
--	--	---------------------	--

### 10.3. Enable/Disable ParametricEQ of Input channel

<b>API :</b>  \Config\Channel#(channel number)PEQ\ParametricEQ			Example – Disable ParametericEQ of input channel 1  <i>Channel number -1</i> <i>Value -0</i>												
<b>Parameters :</b>  <table border="1"><thead><tr><th>Name</th><th>Values/range</th><th>Description</th></tr></thead><tbody><tr><td>channel number</td><td>1-28</td><td>channel number need to be replaced with corresponding input channel number</td></tr><tr><td>Format</td><td>Norm</td><td></td></tr><tr><td>Value</td><td>0-1</td><td>Enable/Disable</td></tr></tbody></table>			Name	Values/range	Description	channel number	1-28	channel number need to be replaced with corresponding input channel number	Format	Norm		Value	0-1	Enable/Disable	<b>Query/Command :</b>  set [{"path":"/Config/Channel1PEQ/ParametricEQ","value":0,"format":"Norm"}]  <b>Response :</b>  @set {"format":"Norm","path":"/Config/Channel1PEQ/ParametricEQ","value":0}
Name	Values/range	Description													
channel number	1-28	channel number need to be replaced with corresponding input channel number													
Format	Norm														
Value	0-1	Enable/Disable													

### 10.4. Reset/Restore all 4 bands value of Input channel

<b>API :</b>  \Config\Channel#(channel number)PEQ\Flatten			Example – Reset all 4 bands  <i>Channel number -1</i> <i>Value -flat</i>												
<b>Parameters :</b>  <table border="1"><thead><tr><th>Name</th><th>Values/range</th><th>Description</th></tr></thead><tbody><tr><td>channel number</td><td>1-28</td><td>channel number need to be replaced with corresponding input channel number</td></tr><tr><td>Format</td><td>Default</td><td></td></tr><tr><td>Value</td><td>Flat, Restore</td><td>Reset or restore</td></tr></tbody></table>			Name	Values/range	Description	channel number	1-28	channel number need to be replaced with corresponding input channel number	Format	Default		Value	Flat, Restore	Reset or restore	<b>Query/Command :</b>  set [{"path":"/Config/Channel1PEQ/Flatten","value": "Flat","format":"Default"}]  <b>Response :</b>  @set {"path":"/Config/Channel1PEQ","value":{"Flatten ":"Flat"}}
Name	Values/range	Description													
channel number	1-28	channel number need to be replaced with corresponding input channel number													
Format	Default														
Value	Flat, Restore	Reset or restore													

## 10.5. Set Frequency of Band (1-4) of Input channel

<b>API :</b>  \Config\Channel#(channel number)PEQ\Band_#(band number)_Frequency	Example – Set Frequency of Band 1 of input channel 1  <i>Channel number -1</i> <i>Band number -1</i> <i>Value - 3340</i>															
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>1-28</td> <td>channel number need to be replaced with corresponding input channel number</td> </tr> <tr> <td>Format</td> <td>Number</td> <td></td> </tr> <tr> <td>Value</td> <td>20-20000</td> <td></td> </tr> <tr> <td>band number</td> <td>1-4</td> <td></td> </tr> </tbody> </table>	Name	Values/range	Description	channel number	1-28	channel number need to be replaced with corresponding input channel number	Format	Number		Value	20-20000		band number	1-4		<b>Query/Command :</b>  set [{"path":"/Config/Channel1PEQ/Band_1_Frequency","value":3338,"format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/Channel1PEQ/Band_1_Frequency","value":"3340"}
Name	Values/range	Description														
channel number	1-28	channel number need to be replaced with corresponding input channel number														
Format	Number															
Value	20-20000															
band number	1-4															

## 10.6. Set Gain of Band (1-4) of Input channel

<b>API :</b>  \Config\Channel#(channel number)PEQ\Band_#(band number)_Gain	Example – Set Gain of Band 1 of Channel 1  Channel number – 1 Band number - 1 Value 8.49															
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>1-28</td> <td>channel number need to be replaced with corresponding input channel number</td> </tr> <tr> <td>Format</td> <td>Number</td> <td></td> </tr> <tr> <td>Value</td> <td>(-20) - 20</td> <td>-20 dB to +20 dB</td> </tr> <tr> <td>Band number</td> <td>1-4</td> <td></td> </tr> </tbody> </table>	Name	Values/range	Description	channel number	1-28	channel number need to be replaced with corresponding input channel number	Format	Number		Value	(-20) - 20	-20 dB to +20 dB	Band number	1-4		<b>Query/Command :</b>  set [{"path":"/Config/Channel1PEQ/Band_1_Gain","value":8.49,"format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/Channel1PEQ/Band_1_Gain","value":"8.5"}
Name	Values/range	Description														
channel number	1-28	channel number need to be replaced with corresponding input channel number														
Format	Number															
Value	(-20) - 20	-20 dB to +20 dB														
Band number	1-4															

## 10.7. Set Q of Band (1-4) of Input channel

<b>API :</b>  \Config\Channel#(channel number)PEQ\Band_#(band number)_Q			Example – Set Q ( width) of Band 1 of Channel 1  Channel number – 1 Band number – 1 Value – 2.76															
<b>Parameters :</b>  <table border="1"><thead><tr><th>Name</th><th>Values/range</th><th>Description</th></tr></thead><tbody><tr><td>channel number</td><td>1-28</td><td>channel number need to be replaced with corresponding input channel number</td></tr><tr><td>Format</td><td>Norm</td><td></td></tr><tr><td>Value</td><td>0.1 -128</td><td></td></tr><tr><td>Band number</td><td>1-4</td><td></td></tr></tbody></table>			Name	Values/range	Description	channel number	1-28	channel number need to be replaced with corresponding input channel number	Format	Norm		Value	0.1 -128		Band number	1-4		<b>Query/Command :</b>  set [{"path":"/Config/Channel1PEQ/Band_1_Q","value":2.76,"format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/Channel1PEQ/Band_1_Q","value":"2.76"}
Name	Values/range	Description																
channel number	1-28	channel number need to be replaced with corresponding input channel number																
Format	Norm																	
Value	0.1 -128																	
Band number	1-4																	

## 10.8. Set Slope of Band (1-4) of Input channel

<b>API :</b>  \Config\Channel#(channel number)PEQ\Band_#(band number)_Slope			Example – Set Slope of Band 4 of Input channel 2  Channel number – 2 Band number – 4 Value – 3.3															
<b>Parameters :</b>  <table border="1"><thead><tr><th>Name</th><th>Values/range</th><th>Description</th></tr></thead><tbody><tr><td>channel number</td><td>1-28</td><td>channel number need to be replaced with corresponding input channel number</td></tr><tr><td>Format</td><td>Number</td><td></td></tr><tr><td>Value</td><td>3-15</td><td></td></tr><tr><td>Band number</td><td>1-4</td><td></td></tr></tbody></table>			Name	Values/range	Description	channel number	1-28	channel number need to be replaced with corresponding input channel number	Format	Number		Value	3-15		Band number	1-4		<b>Query/Command :</b>  set [{"path":"/Config/Channel2PEQ/Band_4_Slope","value":3.3,"format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/Channel2PEQ/Band_4_Slope","value":"3.3"}
Name	Values/range	Description																
channel number	1-28	channel number need to be replaced with corresponding input channel number																
Format	Number																	
Value	3-15																	
Band number	1-4																	

## 10.9. Set Type of Band (1-4) of Input channel

<b>API :</b>  \Config\Channel#(channel number)PEQ\Band_#(band number)_Type	Example – Set Type of Band of PEQ of Input channel 1  Channel number – 1 Band number – 1 Value – “Bell”															
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>1-28</td> <td>channel number need to be replaced with corresponding input channel number</td> </tr> <tr> <td>Format</td> <td>Default</td> <td></td> </tr> <tr> <td>Value</td> <td>{Bell, Low, Shelf, High Shelf}</td> <td></td> </tr> <tr> <td>Band number</td> <td>1-4</td> <td></td> </tr> </tbody> </table>	Name	Values/range	Description	channel number	1-28	channel number need to be replaced with corresponding input channel number	Format	Default		Value	{Bell, Low, Shelf, High Shelf}		Band number	1-4		<b>Query/Command :</b>  set [{"path":"/Config/Channel1PEQ/Band_1_Type","value":"Bell","format":"Default"}]  <b>Response :</b>  @set {"path":"/Config/Output1PEQ","value":{"Band_1_Type":"Bell"}}
Name	Values/range	Description														
channel number	1-28	channel number need to be replaced with corresponding input channel number														
Format	Default															
Value	{Bell, Low, Shelf, High Shelf}															
Band number	1-4															

## 10.10. Set HPFrequency of Output channel

<b>API :</b>  \Config\Output#(channel number)HighPass\Channel_1_HPFrequency	Example – Set HPFrequency of Output channel 1  <i>Channel number – 1</i> <i>Value – 24.6</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>1-12</td> <td>channel number need to be replaced with corresponding input channel number</td> </tr> <tr> <td>Format</td> <td>Number</td> <td></td> </tr> <tr> <td>Value</td> <td>15.9 - 20000</td> <td></td> </tr> </tbody> </table>	Name	Values/range	Description	channel number	1-12	channel number need to be replaced with corresponding input channel number	Format	Number		Value	15.9 - 20000		<b>Query/Command :</b>  set [{"path":"/Config/Output1HighPass/Channel_1_HPFrequency","value":0.12,"format":Norm}]\n\n <b>Response :</b>  @set {"format":Norm,"path":"/Config/Output1HighPass/Channel_1_HPFrequency","value":24.6"}
Name	Values/range	Description											
channel number	1-12	channel number need to be replaced with corresponding input channel number											
Format	Number												
Value	15.9 - 20000												

## 10.11. Set HPType of Output channel

<b>API :</b> <pre>\Config\Output#(channel number)HighPass\Channel_1_HPType</pre>			<b>Example –</b>												
<b>Parameters :</b> <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>1-12</td> <td>channel number need to be replaced with corresponding input channel number</td> </tr> <tr> <td>Format</td> <td>Number</td> <td>( BS 6 BS 12 BS 18 BS 24 BW 6 BW 12 BW 18 BW 24 LR 12 LR 24 )</td> </tr> <tr> <td>Value</td> <td>BS 6 - LR 24</td> <td></td> </tr> </tbody> </table>			Name	Values/range	Description	channel number	1-12	channel number need to be replaced with corresponding input channel number	Format	Number	( BS 6 BS 12 BS 18 BS 24 BW 6 BW 12 BW 18 BW 24 LR 12 LR 24 )	Value	BS 6 - LR 24		<b>Query/Command :</b> <b>Response :</b>
Name	Values/range	Description													
channel number	1-12	channel number need to be replaced with corresponding input channel number													
Format	Number	( BS 6 BS 12 BS 18 BS 24 BW 6 BW 12 BW 18 BW 24 LR 12 LR 24 )													
Value	BS 6 - LR 24														

## 10.12. Enable/Disable ParametricEQ of Output channel

<b>API :</b>  \Config\Output#(channel number)PEQ\ParametricEQ	Example – Disable ParametericEQ of output channel 1  <i>Channel number -1</i> <i>Value -0</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>1-12</td> <td>channel number need to be replaced with corresponding input channel number</td> </tr> <tr> <td>Format</td> <td>Number</td> <td></td> </tr> <tr> <td>Value</td> <td>0-1</td> <td>Enable/Disable</td> </tr> </tbody> </table>	Name	Values/range	Description	channel number	1-12	channel number need to be replaced with corresponding input channel number	Format	Number		Value	0-1	Enable/Disable	<b>Query/Command :</b>  set [{"path":"/Config/Output1PEQ/ParametricEQ","value":0,"format":"Norm"}]  <b>Response :</b>  @set {"format":"Norm","path":"/Config/Output1PEQ/ParametricEQ","value":0}
Name	Values/range	Description											
channel number	1-12	channel number need to be replaced with corresponding input channel number											
Format	Number												
Value	0-1	Enable/Disable											

## 10.13. Reset/Restore all 4 bands value of Output channel

<b>API :</b>  \Config\Output#(channel number)PEQ\Flatten	Example – Reset all 4 bands  <i>Channel number -1</i> <i>Value -flat</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>1-12</td> <td>channel number need to be replaced with corresponding input channel number</td> </tr> <tr> <td>Format</td> <td>Default</td> <td></td> </tr> <tr> <td>Value</td> <td>Flat, Restore</td> <td>Reset or restore</td> </tr> </tbody> </table>	Name	Values/range	Description	channel number	1-12	channel number need to be replaced with corresponding input channel number	Format	Default		Value	Flat, Restore	Reset or restore	<b>Query/Command :</b>  set [{"path":"/Config/Output1PEQ/Flatten","value":"Flat","format":"Default"}]  <b>Response :</b>  @set {"path":"/Config/Output1PEQ","value":{"Flatten":"Flat"}}
Name	Values/range	Description											
channel number	1-12	channel number need to be replaced with corresponding input channel number											
Format	Default												
Value	Flat, Restore	Reset or restore											

## 10.14. Set Frequency of Band (1-4) of Output channel

<b>API :</b>  \Config\Output#(channel number)PEQ\Band_#(band number)_Frequency			Example – Set Frequency of															
<b>Parameters :</b> <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>1-12</td> <td>channel number need to be replaced with corresponding input channel number</td> </tr> <tr> <td>Format</td> <td>Number</td> <td></td> </tr> <tr> <td>Value</td> <td>20-20000</td> <td></td> </tr> <tr> <td>Band number</td> <td>1-4</td> <td></td> </tr> </tbody> </table>			Name	Values/range	Description	channel number	1-12	channel number need to be replaced with corresponding input channel number	Format	Number		Value	20-20000		Band number	1-4		<b>Query/Command :</b>  set [{"path":"/Config/Output1PEQ/Band_1_Frequency","value":"49","format":"Number"}]
Name	Values/range	Description																
channel number	1-12	channel number need to be replaced with corresponding input channel number																
Format	Number																	
Value	20-20000																	
Band number	1-4																	

**Response :**

```
@set {"format": "Number"
,"path":"/Config/Output1PEQ/Band_1_Frequency","value":"49"}
```

## 10.15. Set Gain of Band (1-4) of Output channel

<b>API :</b>  \Config\Output#(channel number)PEQ\Band_#(band number)_Gain			Example – Set Gain of Band 1 of Output channel 1  Channel number – 1 Band number - 1															
<b>Parameters :</b> <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>1-12</td> <td>channel number need to be replaced with corresponding input channel number</td> </tr> <tr> <td>Format</td> <td>Number</td> <td></td> </tr> <tr> <td>Value</td> <td>(-20) - 20</td> <td>decimal values within range accepted</td> </tr> <tr> <td>Band number</td> <td>1-4</td> <td></td> </tr> </tbody> </table>			Name	Values/range	Description	channel number	1-12	channel number need to be replaced with corresponding input channel number	Format	Number		Value	(-20) - 20	decimal values within range accepted	Band number	1-4		<b>Query/Command :</b>  set [{"path":"/Config/Output1PEQ/Band_1_Gain","value":"10","format":"Number"}]
Name	Values/range	Description																
channel number	1-12	channel number need to be replaced with corresponding input channel number																
Format	Number																	
Value	(-20) - 20	decimal values within range accepted																
Band number	1-4																	

**Response :**

```
@set {"format": "Number"
,"path":"/Config/Output1PEQ/Band_1_Gain","value":"10"}
```

## 10.16. Set Q of Band (1-4) of Output channel

<b>API :</b>  \Config\Output#(channel number)PEQ\Band_#(band number)_Q			Example – Set Q (width) of Band 1 of Output channel 1 (PEQ)
<b>Parameters :</b>			<b>Query/Command :</b>
<b>Name</b>	<b>Values/range</b>	<b>Description</b>	<p><b>Query/Command :</b></p> <pre>set [{"path":"/Config/Output1PEQ/Band_1_Q","value":1.86,"format":"Number"}]</pre> <p><b>Response :</b></p> <pre>@set {"format":"Number","path":"/Config/Output1PEQ/Band_1_Q","value":"1.84"}</pre>
channel number	1-12	channel number need to be replaced with corresponding input channel number	
Format	Number		
Value	0.1 - 128		
Band number	1-4		

## 10.17. Set Slope of Band (1-4) of Output channel

<b>API :</b>  \Config\Output#(channel number)PEQ\Band_#(band number)_Slope			Example – Set Slope value of band 1 of output channel 1 ( PEQ)
<b>Parameters :</b>			<b>Query/Command :</b>
<b>Name</b>	<b>Values/range</b>	<b>Description</b>	<p><b>Query/Command :</b></p> <pre>set [{"path":"/Config/Output1PEQ/Band_1_Slope","value":3.3,"format":"Number"}]</pre> <p><b>Response :</b></p> <pre>@set {"format":"Number","path":"/Config/Output1PEQ/Band_1_Slope","value":"3.3"}</pre>
channel number	1-12	channel number need to be replaced with corresponding input channel number	
Format	Number		
Value	3 -15		
Band number	1-4		

## 10.18. Set Type of Band (1-4) of Output channel

<b>API :</b>  \Config\Output#(channel number)PEQ\Band_#(band number)_Type	Example – Set Type of Band of PEQ of Output channel 1  Channel number – 1 Band number – 1 Value – “Bell”															
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>1-12</td> <td>channel number need to be replaced with corresponding input channel number</td> </tr> <tr> <td>Format</td> <td>Norm</td> <td></td> </tr> <tr> <td>Value</td> <td>{Bell, Low, Shelf, High Shelf}</td> <td></td> </tr> <tr> <td>Band number</td> <td>1-4</td> <td></td> </tr> </tbody> </table>	Name	Values/range	Description	channel number	1-12	channel number need to be replaced with corresponding input channel number	Format	Norm		Value	{Bell, Low, Shelf, High Shelf}		Band number	1-4		<b>Query/Command :</b>  set [{"path":"/Config/Output1PEQ/Band_1_Type","v alue":"Bell","format":"Default"}]  <b>Response :</b>  @set {"path":"/Config/Output1PEQ","value":{"Band_1 _Type":"Bell"}}  
Name	Values/range	Description														
channel number	1-12	channel number need to be replaced with corresponding input channel number														
Format	Norm															
Value	{Bell, Low, Shelf, High Shelf}															
Band number	1-4															

## 11. Configure Matrix Router

### 11.1. Select/Assign channel in Input channel (1-28)

Please refer 2.1

### 11.2. Select/Assign channel in Output channel (1-12)

Please refer 3.0

### 11.3. Select/Assign input channel in Automixer (1-4)

<b>API :</b> <pre>/Config/MatrixRouter/Automixer_#(auto mixer number)_Input_#(channel number**)_Connection</pre>			Example – Assign Input channel 5 to Automixer 1 (i.e. Conference 1)  <i>Channel number -5</i> <i>Automixer number -1</i>															
<b>Parameters :</b> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>1-12</td> <td>channel number need to be replaced with corresponding input channel number</td> </tr> <tr> <td>Format</td> <td>Norm</td> <td></td> </tr> <tr> <td>Value</td> <td>0-1</td> <td>Remove/Add from automixer group</td> </tr> <tr> <td>Automixer number</td> <td>1-4</td> <td></td> </tr> </tbody> </table>			Name	Values/range	Description	channel number	1-12	channel number need to be replaced with corresponding input channel number	Format	Norm		Value	0-1	Remove/Add from automixer group	Automixer number	1-4		<b>Query/Command :</b>  set [{"path":"/Config/MatrixRouter/Automixer_1_Input_5_Connection","value":1,"format":"Norm"}]  <b>Response :</b>  @set {"format":"Norm","path":"/Config/MatrixRouter/Automixer_1_Input_5_Connection","value":1}
Name	Values/range	Description																
channel number	1-12	channel number need to be replaced with corresponding input channel number																
Format	Norm																	
Value	0-1	Remove/Add from automixer group																
Automixer number	1-4																	

## 11.4. Select/Assign output channel in Automixer (1-4)

<b>API :</b> <pre>/Config/MatrixRouter/Automixer_#(auto mixer number)_Output_#(channel number)**_Connection</pre>			Example – Assign output channel 7 to Automixer 3 (i.e. Conference 3)  <i>Channel number -7</i> <i>Automixer number -3</i>															
<b>Parameters :</b> <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>channel number</td> <td>1-12</td> <td>channel number need to be replaced with corresponding input channel number</td> </tr> <tr> <td>Format</td> <td>Norm</td> <td></td> </tr> <tr> <td>Value</td> <td>0-1</td> <td>Remove/Add from automixer group</td> </tr> <tr> <td>Auto mixer number</td> <td>1-4</td> <td>Auto mixer number has to be replaced with actual automixer number (conference number)</td> </tr> </tbody> </table>			Name	Values/range	Description	channel number	1-12	channel number need to be replaced with corresponding input channel number	Format	Norm		Value	0-1	Remove/Add from automixer group	Auto mixer number	1-4	Auto mixer number has to be replaced with actual automixer number (conference number)	<b>Query/Command :</b>  set [{"path":"/Config/MatrixRouter/Automixer_3_Output_7_Connection","value":1,"format":"Norm"}]
Name	Values/range	Description																
channel number	1-12	channel number need to be replaced with corresponding input channel number																
Format	Norm																	
Value	0-1	Remove/Add from automixer group																
Auto mixer number	1-4	Auto mixer number has to be replaced with actual automixer number (conference number)																
<b>Response :</b>  @set {"format":"Norm","path":"/Config/MatrixRouter/Automixer_3_Output_7_Connection","value":1}																		

## 11.5. Set MasterGain of Automixer (1-4) (Same as section 5.1)

<b>API :</b> <pre>/Config/MatrixRouter/AutoMixer_#(automixer number)_MasterGain</pre>			Example – Set master gain of Automixer 1  <i>auto mixer number -1</i> <i>Value - .98</i>												
<b>Parameters :</b> <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Auto mixer number</td> <td>1-4</td> <td>Auto mixer number has to be replaced with actual automixer number (conference number)</td> </tr> <tr> <td>Format</td> <td>Number</td> <td></td> </tr> <tr> <td>Value</td> <td>(-80) – (10)</td> <td></td> </tr> </tbody> </table>			Name	Values/range	Description	Auto mixer number	1-4	Auto mixer number has to be replaced with actual automixer number (conference number)	Format	Number		Value	(-80) – (10)		<b>Query/Command :</b>  set [{"path":"/Config/MatrixRouter/AutoMixer_1_MasterGain","value":1,"format":"Number"}]
Name	Values/range	Description													
Auto mixer number	1-4	Auto mixer number has to be replaced with actual automixer number (conference number)													
Format	Number														
Value	(-80) – (10)														

## 11.6. Set Speed of Automixer (1-4) (Same as section 5.5)

<b>API :</b>  /Config/MatrixRouter/Automixer_#(automixer number)_Speed			Example – Set Speed value of Automixer 1  Automixer number – 1 Value – 0.05												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Auto mixer number</td> <td>1-4</td> <td>Auto mixer number has to be replaced with actual automixer number ( conference number)</td> </tr> <tr> <td>Format</td> <td>Number</td> <td></td> </tr> <tr> <td>Value</td> <td>0.05 - 10</td> <td></td> </tr> </tbody> </table>			Name	Values/range	Description	Auto mixer number	1-4	Auto mixer number has to be replaced with actual automixer number ( conference number)	Format	Number		Value	0.05 - 10		<b>Query/Command :</b>  set [{"path":"/Config/MatrixRouter/AutoMixer_1_Speed","value":"0","format":"Number"}]
Name	Values/range	Description													
Auto mixer number	1-4	Auto mixer number has to be replaced with actual automixer number ( conference number)													
Format	Number														
Value	0.05 - 10														

**Response :**

```
@set
{"format":"Number","path":"/Config/MatrixRouter/AutoMixer_1_Speed","value":"0.05"}
```

## 11.7. Set Ratio (Slope) of Automixer (1-4) (Same as section 5.4)

<b>API :</b>  /Config/MatrixRouter/Automixer_#(automixer number)_Ratio			Example – Set ratio value <i>automixer number – 1</i> <i>value – 1.4</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Auto mixer number</td> <td>1-4</td> <td>Automixer number has to be replaced with actual automixer number ( conference number)</td> </tr> <tr> <td>Format</td> <td>Number</td> <td></td> </tr> <tr> <td>Value</td> <td>1 - 2</td> <td></td> </tr> </tbody> </table>			Name	Values/range	Description	Auto mixer number	1-4	Automixer number has to be replaced with actual automixer number ( conference number)	Format	Number		Value	1 - 2		<b>Query/Command :</b>  set [{"path":"/Config/MatrixRouter/AutoMixer_1_Ratio","value":"1.4","format":"Number"}]
Name	Values/range	Description													
Auto mixer number	1-4	Automixer number has to be replaced with actual automixer number ( conference number)													
Format	Number														
Value	1 - 2														

**Response :**

```
@set
{"format":"Number","path":"/Config/MatrixRouter/AutoMixer_1_Ratio","value":"1.4"}
```

## 11.8. Mute Automixer (1-4) (Same as section 5.3)

<b>API :</b>  /Config/MatrixRouter/Automixer_#(automixer number)_MasterMute			Example – Mute Automixer 1  <i>auto mixer number -1</i> <i>value -1</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Auto mixer number</td> <td>1-12</td> <td>Auto mixer number has to be replaced with actual automixer number ( conference number)</td> </tr> <tr> <td>Format</td> <td>Norm</td> <td></td> </tr> <tr> <td>Value</td> <td>0-1</td> <td>0 – Unmute 1- Mute</td> </tr> </tbody> </table>			Name	Values/range	Description	Auto mixer number	1-12	Auto mixer number has to be replaced with actual automixer number ( conference number)	Format	Norm		Value	0-1	0 – Unmute 1- Mute	<b>Query/Command :</b>  set [{"path":"/Config/MatrixRouter/AutoMixer_1_MasterMute","value":1,"format":"Norm"}]  <b>Response :</b>  @set {"format":"Norm","path":"/Config/MatrixRouter/AutoMixer_1_MasterMute","value":"1"}
Name	Values/range	Description													
Auto mixer number	1-12	Auto mixer number has to be replaced with actual automixer number ( conference number)													
Format	Norm														
Value	0-1	0 – Unmute 1- Mute													

## 12. BLU Link Settings

### 12.1. Read version

API : /Config/Blulink/Version			Example – Read blu link version
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	get [{"path":"/Config/Blulink/Version","format":"Default"}]
Format	Default		<b>Response :</b>

### 12.2. Read Master MAC address

API : /Config/Blulink/MasterMacAddr			Example – Read master MAC address
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	get [{"path":"/Config/Blulink/MasterMacAddr","format":"Default"}]
Format	Default		<b>Response :</b>

### 12.3. Read Master Priority

API : /Config/Blulink/MasterPriority			Example –
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	get [{"path":"/Config/Blulink/MasterPriority","format":"Number"}]
Format	Number		<b>Response :</b>  @get {"format":"Number", "path":"/Config/Blulink/MasterPriority", "value":"64"} 

## 12.4. Read Sample Rate

API :			Example –
/Config/Blulink/SampleRate			
Parameters :			<b>Query/Command :</b>
Name	Values/range	Description	
Format	Default		<p>get [{"path":"/Config/Blulink/SampleRate","format":"Default"}]</p> <p><b>Response :</b></p> <pre>@get {"format":"Default","path":"/Config/Blulink/ SampleRate ","value":"48 kHz"}</pre>

## 12.5. Set Priority

API :			Example – Set Priority value
/Config/Blulink/Priority			Value - 37
Parameters :			<b>Query/Command :</b>
Name	Values/range	Description	
Format	Default		<p>set [{"path":"/Config/Blulink/Priority","value":37,"fo rmat":"Number"}]</p> <p><b>Response :</b></p> <pre>@set {"format":"Number","path":"/Config/Blulink/Prio rity","value":"37"}</pre>
value	0-254		

## 12.6. Read Input port status

<b>API :</b>  /Config/Blulink/InputPortStatus			Example – Read input port status
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	<b>get</b> [{"path":"/Config/Blulink/InputPortStatus","format":"Default"}]  <b>Response :</b>  <b>@get</b> {"format":"Default","path":"/Config/Blulink/InputPortStatus","value":"NotConnected"}

## 12.7. Read Output port status

<b>API :</b>  /Config/Blulink/OutputPortStatus			Example – Read output port status
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	<b>get</b> [{"path":"/Config/Blulink/OutputPortStatus","format":"Default"}]  <b>Response :</b>  <b>@get</b> {"format":"Default","path":"/Config/Blulink/OutputPortStatus","value":"NotConnected"}

## 12.8. Read Input correct count

API :			Example –
/Config/Blulink/InputCorrectCount			
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	
Format	Number		<p>get [{"path":"/Config/Blulink/InputCorrectedCount", "format":"Number"}]</p> <p><b>Response :</b></p> <pre>@get {"format":"Number","path":"/Config/Blulink/InputCorrectedCount","value":"0"}</pre>

## 12.9. Read Output correct count

API :			Example – Read output correct count
/Config/Blulink/OutputCorrectCount			
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	
Format	Number		<p>get [{"path":"/Config/Blulink/OutputCorrectedCount", "format":"Number"}]</p> <p><b>Response :</b></p> <pre>@get {"format":"Number","path":"/Config/Blulink/OutputCorrectedCount","value":"0"}</pre>

## 12.10. Read Input error count

<b>API :</b>  /Config/Blulink/InputErrorCount			Example – Read Input error count
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	<b>get</b> [{"path":"/Config/Blulink/InputErrorCount","format":"Number"}]  <b>Response :</b>  @get {"format":"Number","path":"/Config/Blulink/InputErrorCount","value":"0"}

## 12.11. Read Output error count

<b>API :</b>  /Config/Blulink/OutputErrorCount			Example – Read Output error count
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	<b>get</b> [{"path":"/Config/Blulink/OutputErrorCount","format":"Number"}]  <b>Response :</b>  @get {"format":"Number","path":"/Config/Blulink/OutputErrorCount","value":"0"}

## 12.12. Reset Input error

<b>API :</b>  /Config/Blulink/InputErrorReset	Example – Reset Input error count									
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Format</td> <td>Default</td> <td></td> </tr> <tr> <td>Value</td> <td>1</td> <td></td> </tr> </tbody> </table>	Name	Values/range	Description	Format	Default		Value	1		<b>Query/Command :</b>  set [{"path":"/Config/Blulink/InputErrorReset","value":1,"format":"Number"}]
Name	Values/range	Description								
Format	Default									
Value	1									

**Response :**

```
@set
{"format":"Number","path":"/Config/Blulink/Inp
utErrorReset","value":"0"}
```

## 12.13. Reset Output error

<b>API :</b>  /Config/Blulink/OutputErrorReset	Example – Reset output error count						
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Format</td> <td>Default</td> <td></td> </tr> </tbody> </table>	Name	Values/range	Description	Format	Default		<b>Query/Command :</b>  set [{"path":"/Config/Blulink/OutputErrorReset","value":1,"format":"Number"}]
Name	Values/range	Description					
Format	Default						

**Response :**

```
@set
{"format":"Number","path":"/Config/Blulink/Out
putErrorReset","value":"0"}
```

## 13. Device Settings

### 13.1. Disable/Set Home screen timeout value

<b>API :</b>  /Home Screen Timeout			Example – Set “3 min” as home screen timeout value  <i>Value – 3 min</i>
<b>Parameters :</b>			<b>Query/Command :</b>  set [{"path":"/Home Screen Timeout","value":"3 min","format":"Default"}]
<b>Name</b>	<b>Values/range</b>	<b>Description</b>	<b>Response :</b>  publish {"path":"/","value":{"Home Screen Timeout":"3 min"}} @set {"path":"/","value":{"Home Screen Timeout":"3 min"}}
Format	Default		
value	Disabled 10 min 5 min 4 min 3 min 2 min 1 min 30 sec 10 sec		

### 13.2. Disable/Set Backlight timeout value

<b>API :</b>  /Backlight Timeout			Example – Set “30 sec” as home screen timeout value  <i>Value – 3 sec</i>
<b>Parameters :</b>			<b>Query/Command :</b>  set [{"path":"/Backlight Timeout","value":"30 sec","format":"Default"}]
<b>Name</b>	<b>Values/range</b>	<b>Description</b>	<b>Response :</b>  publish {"path":"/","value":{"Backlight Timeout":"30 sec"}} @set {"path":"/","value":{"Backlight Timeout":"30 sec"}}
Format	Default		
value	Disabled 10 min 5 min 4 min 3 min 2 min 1 min 30 sec 10 sec		

### 13.3. Lock/Unlock Front panel

<b>API :</b>  /Front Panel Lockout			Example – Lock front panel  <i>Value – Locked</i>
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	set [{"path":"/Front Panel Lockout","value":"Locked","format":"Default"}]
Format  value	Default  Locked Unlocked		<b>Response :</b>  @set {"path":"/","value":{"Front Panel Lockout":"Locked"}}

### 13.4. Subscribe Firmware update status

<b>API :</b>  /fwUpdStatus			Example – Subscribe firmware update status  <i>Value – Locked</i>
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	subscribe [{"path":"/fwUpdStatus","format":"Number"}]
Format	Number		<b>Response :</b>  @subscribe {"format":"Number","path":"/fwUpdStatus","value":"0"}

### 13.5. Subscribe / Unsubscribe version value

<b>API :</b>  /commonConfig/version			Example – Subscribe version value
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	subscribe [{"path":"/fwUpdStatus","format":"Number"}]
Format			<b>Response :</b>

## 14. Exec Commands

### 14.1. Save Configuration

<b>API :</b>  Path - / Command - ConfigBackup	Example – Save Configuration  <i>Arguments – name of configuration ( i.e. Test)</i>						
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Argument s</td> <td>string name of the configuration</td> <td></td> </tr> </tbody> </table>	Name	Values/range	Description	Argument s	string name of the configuration		<b>Query/Command :</b>  <pre>exec {"path":"/","command":"ConfigBackup","arguments":"Test"}</pre> <b>Response :</b>  <pre>@exec {"arguments":"Command OK","command":"ConfigBackup","path":"/"}</pre>
Name	Values/range	Description					
Argument s	string name of the configuration						

### 14.2. Restore Configuration

<b>API :</b>  Path - / Command - ConfigRestore	Example – Restore/Load some existing configuration  <i>Arguments – configuration name</i>						
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Argument s</td> <td>string name of the configuration</td> <td></td> </tr> </tbody> </table>	Name	Values/range	Description	Argument s	string name of the configuration		<b>Query/Command :</b>  <pre>exec {"path":"/","command":"ConfigRestore","arguments":"Test"}</pre> <b>Response :</b>  <pre>@exec {"arguments":"Test","command":"ConfigRestore", ,"path":"/"}</pre>
Name	Values/range	Description					
Argument s	string name of the configuration						

## 14.3. Create Configuration

<b>API :</b>  Path - / Command - ConfigCreate	Example – Create new configuration  <i>Arguments – name of configuration (i.e. temp)</i>						
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Argument s</td> <td>string name of the configuration</td> <td></td> </tr> </tbody> </table>	Name	Values/range	Description	Argument s	string name of the configuration		<b>Query/Command :</b>  <pre>exec {"path":"/","command":"ConfigCreate","arguments":"Temp"}</pre> <b>Response :</b>  <pre>@exec {"arguments":"Temp","command":"ConfigCreate","path":"/"}</pre>
Name	Values/range	Description					
Argument s	string name of the configuration						

## 14.4. Validate Configuration

<b>API :</b>  Path - / Command - ConfigValidate	Example –  <i>arguments - filename + extension</i>						
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Argument s</td> <td>string name of the configuration</td> <td></td> </tr> </tbody> </table>	Name	Values/range	Description	Argument s	string name of the configuration		<b>Query/Command :</b>  <pre>exec {"path":"/","command":"ConfigValidate","arguments":"Sample.dnp"}</pre> <b>Response :</b>  
Name	Values/range	Description					
Argument s	string name of the configuration						

## 14.5. Rename Configuration

<b>API :</b>  Path - / Command - ConfigRename	Example – Rename existing configuration ("Entour" to "Rumble")  <i>Arguments – ["old name", "new name"]</i>						
<b>Parameters :</b>  <table> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Arguments</td> <td>string name of the configuration</td> <td></td> </tr> </tbody> </table>	Name	Values/range	Description	Arguments	string name of the configuration		<b>Query/Command :</b>  exec {"path": "/", "command": "ConfigRename", "arguments": ["Entour", "Rumble"]}  <b>Response :</b>  @exec {"arguments": "Command OK", "command": "ConfigRename", "path": "/"}
Name	Values/range	Description					
Arguments	string name of the configuration						

## 14.6. Reconfigure mono-stereo

<b>API :</b>  Path - / Command - reconfigure	Example – Rename existing configuration ("Entour" to "Rumble")  <i>Arguments – {"version": 1, "inputs": {"1": {}, "2": {}, "3": {}, "4": {}}, "13": {}, "14": {"linkage": 0}, "15": {"linkage": 1}, "16": {}, "17": {"linkage": 0}, "18": {"linkage": 1}, "19": {}, "20": {}, "outputs": {"1": {}, "2": {}, "3": {"linkage": 0}, "4": {"linkage": 1}, "5": {}, "6": {"linkage": 0}, "7": {"linkage": 1}, "8": {}, "9": {}, "10": {}, "11": {}, "12": {}}}</i>						
<b>Parameters :</b>  <table> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Arguments</td> <td>string</td> <td>json string representing the configuration</td> </tr> </tbody> </table>	Name	Values/range	Description	Arguments	string	json string representing the configuration	<b>Query/Command :</b>  <b>Response :</b>
Name	Values/range	Description					
Arguments	string	json string representing the configuration					

## 14.7. Change password

<b>API :</b>  Path - / Command – pwd	Example – Change password “ <i>Arguments – [“username, “new password”]</i>						
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Argument s</td> <td>string</td> <td>json string representing the configuration</td> </tr> </tbody> </table>	Name	Values/range	Description	Argument s	string	json string representing the configuration	<b>Query/Command :</b>  exec { "path": "/", "command": "pwd", "arguments": ["administrator", "admin"] }  <b>Response :</b>  @exec {"arguments": "Password set OK", "command": "pwd", "path": "/"}
Name	Values/range	Description					
Argument s	string	json string representing the configuration					

## 14.8. Login

<b>API :</b>  Path - / Command – login	Example – Change password “ <i>Arguments – [“username, “password”]</i>						
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Argument s</td> <td>string</td> <td></td> </tr> </tbody> </table>	Name	Values/range	Description	Argument s	string		<b>Query/Command :</b>  exec { "path": "/", "command": "login", "arguments": ["administrator", "admin"] }  <b>Response :</b>
Name	Values/range	Description					
Argument s	string						

## 14.9. Start firmware update

<b>API :</b>  Path - / Command - fwupdate	Example – Start firmware update “ <i>Arguments – ['start',fwupdate file URL]</i>						
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Argument s</td> <td>start</td> <td>string</td> </tr> </tbody> </table>	Name	Values/range	Description	Argument s	start	string	<b>Query/Command :</b>  exec { "path": "/", "command": "fwupdate", "arguments": :"start"}  <b>Response :</b>
Name	Values/range	Description					
Argument s	start	string					

## 14.10. Cancel firmware update

<b>API :</b>  Path - / Command - fwupdate	Example – Cancel firmware update “ <i>Arguments – ['cancel']</i>						
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Argument s</td> <td>cancel</td> <td>string</td> </tr> </tbody> </table>	Name	Values/range	Description	Argument s	cancel	string	<b>Query/Command :</b>  exec { "path": "/", "command": "fwupdate", "arguments": :"cancel"}  <b>Response :</b>
Name	Values/range	Description					
Argument s	cancel	string					

## 14.11. Locate On/Off

API : Path - / Command - locate			Example – Locate the device “ <i>Arguments – ['on']</i>
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	<b>exec</b> { "path": "/", "command": "locate", "arguments": "On" }  <b>Response :</b> @exec {"arguments": "locate On", "command": "locate", "path": "/"}

## 14.12. Factory reset

API : Path - / Command - factoryreset			Example – Factory reset <i>Arguments – ['on']</i>
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	<b>exec</b> { "path": "/", "command": "factoryreset", "arguments": "On" }  <b>Response :</b>

## 14.13. Change IP Address

API : Path - /commonConfig Command – setip			Example – Change the IP Address of device <i>Arguments – { "name" : "eth0", "mac" : "00:0f:d4:01:e7:81", "ipv4" : "10.34.6.98", "subnet" : "255.255.255.0", "gateway" : "10.34.6.1", "dhcp" : true, "ipv" : "v4" }</i>
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	<b>Response :</b>
Argument s	On	json string with network	

## 15. Network Settings

### 15.1. Network configuration of Port A (AES67)

<b>API :</b>  Path - /commonConfig Command - setip	Example – Change network settings  <i>Arguments</i> –						
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Argument s</td> <td>string</td> <td></td> </tr> </tbody> </table>	Name	Values/range	Description	Argument s	string		<b>Query/Command :</b>  exec <pre>{"path":"/commonConfig","command":"setip","a rguments":{"mac":"00:0F:D4:01:E7:BA","ipv6":" ,"ipv":"v4","dhcp":false,"ipv4":"10.90.76.167", "subnet":"255.255.254.0","gateway":"10.90.76.1", "name":"eth0"}}</pre> <b>Response :</b>  <pre>@exec {"arguments":"Setip name:eth0 mac:00:0F:D4:01:E7:BA ipv4:10.90.76.167 subnet:255.255.254.0 gateway:10.90.76.1 dhcp:false ipv:v4 ipv6:","command":"setip","path":"/commonConf ig"} publish {"format":"Norm","path":"/commonConfig/nwIn terfaces/i1/dhcp","value":"0"}</pre>
Name	Values/range	Description					
Argument s	string						

### 15.2. Network Configuration of Port B (VoIP)

<b>API :</b>  Path - /commonConfig Command - setip	Example – Change network settings of Port B  <i>Arguments</i> –						
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Argument s</td> <td>string</td> <td></td> </tr> </tbody> </table>	Name	Values/range	Description	Argument s	string		<b>Query/Command :</b>  exec <pre>{"path":"/commonConfig","command":"setip","a rguments":{"mac":"","ipv6":"","ipv":"v4","dhcp": true,"ipv4":"","subnet":"","gateway":"","name":" eth1"}}</pre> <b>Response :</b>
Name	Values/range	Description					
Argument s	string						

## 16. VoIP settings (VoIP Screen)

### 16.1. Get account status

<b>API :</b>  /Config/VoIP/Channel_#(channel number)_AccountStatus	Example – Get status of channel 4  <i>Channel number – 4</i>						
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> </tbody> </table>	Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	<b>Query/Command :</b>  get [{"path":"/Config/VoIP/Channel_4_AccountStatus","format":"Default"}]  <b>Response :</b>  @get {"path":"/Config/VoIP","value":{"Channel_4_AccountStatus":"NotRegistered (0)}}
Name	Values/range	Description					
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number					

### 16.2. Set user name

<b>API :</b>  /Config/VoIP/Channel_#(channel number)_UserName	Example – Set user name of channel 1  <i>Channel number – 1</i> <i>Value - ravikant</i>												
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format</td> <td>Default</td> <td></td> </tr> <tr> <td>Value</td> <td>String</td> <td>Valid string value</td> </tr> </tbody> </table>	Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format	Default		Value	String	Valid string value	<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_UserName","value":"RaviKant","format":"Default"}]  <b>Response :</b>  publish {"path":"/Config/VoIP","value":{"Channel_1_UserName":"RaviKant"}} @set {"path":"/Config/VoIP","value":{"Channel_1_UserName":"RaviKant"}}
Name	Values/range	Description											
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number											
Format	Default												
Value	String	Valid string value											

### 16.3. Set Authentication user name

<b>API :</b> <pre>/Config/VoIP/Channel_#(channel number)_AuthUser</pre>			Example – Set Authentication name for VoIP channel 1  <i>Channel number – 1</i> <i>Value – VoIP1</i>									
<b>Parameters :</b> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Default String</td> <td>Valid string value</td> </tr> </tbody> </table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Default String	Valid string value	<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_AuthUser","value":"VoIP1","format":"Default"}]
Name	Values/range	Description										
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number										
Format value	Default String	Valid string value										
<b>Response :</b>  @set {"path":"/Config/VoIP","value":{"Channel_1_AuthUser":"VoIP1"}}												

### 16.4. Set Password

<b>API :</b> <pre>/Config/VoIP/Channel_#(channel number)_AuthPassword</pre>			Example – Set password of VoIP channel 1  <i>Channel number – 1</i> <i>Password - Test</i>									
<b>Parameters :</b> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Default String</td> <td>Valid string value</td> </tr> </tbody> </table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Default String	Valid string value	<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_AuthPassword","value":"Test","format":"Default"}]
Name	Values/range	Description										
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number										
Format value	Default String	Valid string value										
<b>Response :</b>  @set {"path":"/Config/VoIP","value":{"Channel_1_AuthPassword":"Test"}}												

## 16.5. Set Display name

<b>API :</b>  <i>/Config/VoIP/Channel_#(channel number)_DisplayName</i>			Example – Set Display name of VoIP 1  <i>Channel number – 1</i> <i>Value - DCP</i>									
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Default String</td> <td>Valid string value</td> </tr> </tbody> </table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Default String	Valid string value	<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_DisplayName","value":"DCP","format":"Default"}]  <b>Response :</b>  @set {"path":"/Config/VoIP","value":{"Channel_1_DisplayName":"DCP"}}
Name	Values/range	Description										
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number										
Format value	Default String	Valid string value										

## 16.6. Set Domain value

<b>API :</b>  <i>/Config/VoIP/Channel_#(channel number)_Domain</i>			Example – Set domain value of VoIP 1  <i>Channel number – 1</i> <i>Value – dcp.voip.server</i>									
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Default String</td> <td>Valid string value</td> </tr> </tbody> </table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Default String	Valid string value	<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_Domain","value":"dcp.voip.server","format":"Default"}]  <b>Response :</b>  @set {"path":"/Config/VoIP","value":{"Channel_1_Domain":"dcp.voip.server"}}
Name	Values/range	Description										
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number										
Format value	Default String	Valid string value										

## 16.7. Enable/Disable Stun

<b>API :</b>  /Config/VoIP/Channel_#(channel number)_StunEnabled			Example – Enable stun for Channel 1  <i>Channel number -1</i> <i>Value - 1</i>												
<b>Parameters :</b>  <table border="1"><thead><tr><th>Name</th><th>Values/range</th><th>Description</th></tr></thead><tbody><tr><td>Channel number</td><td>1-4</td><td>Channel number has to be replaced with actual VoIP channel number</td></tr><tr><td>Format</td><td>Default</td><td></td></tr><tr><td>value</td><td>0-1</td><td>0-Disable 1-Enable</td></tr></tbody></table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format	Default		value	0-1	0-Disable 1-Enable	<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_StunEnabled","value":1,"format":"Norm"}]  <b>Response :</b>  publish {"format":"Norm","path":"/Config/VoIP/Channel_1_StunEnabled","value":1} @set {"format":"Norm","path":"/Config/VoIP/Channel_1_StunEnabled","value":1}
Name	Values/range	Description													
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number													
Format	Default														
value	0-1	0-Disable 1-Enable													

## 16.8. Enable/Disable “Register with domain” option

<b>API :</b>  /Config/VoIP/Channel_#(channel number)_RegisterWithDomain			Example – Disable “Register with domain” option of VoIP 1  Channel number – 1 Value - 0												
<b>Parameters :</b>  <table border="1"><thead><tr><th>Name</th><th>Values/range</th><th>Description</th></tr></thead><tbody><tr><td>Channel number</td><td>1-4</td><td>Channel number has to be replaced with actual VoIP channel number</td></tr><tr><td>Format</td><td>Default</td><td></td></tr><tr><td>value</td><td>0-1</td><td>0-Disable 1-Enable</td></tr></tbody></table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format	Default		value	0-1	0-Disable 1-Enable	<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_RegisterWithDomain","value":0,"format":"Norm"}]  <b>Response :</b>  @set {"format":"Norm","path":"/Config/VoIP/Channel_1_RegisterWithDomain","value":0}
Name	Values/range	Description													
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number													
Format	Default														
value	0-1	0-Disable 1-Enable													

## 16.9. Set Registration life value

<b>API :</b>  <i>/Config/VoIP/Channel_#(channel number)_RegistrationLife</i>			Example – Set registration life value of VoIP 1  <i>Channel number – 1</i> <i>Value - 3599</i>							
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Default</td> <td></td> </tr> </tbody> </table>	Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Default		<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_RegistrationLife","value":3599,"format":"Default"}]  <b>Response :</b>  @set {"path":"/Config/VoIP","value":{"Channel_1_RegistrationLife":3599}}
Name	Values/range	Description								
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number								
Format value	Default									

## 16.10. Set Registration retry value

<b>API :</b>  <i>/Config/VoIP/Channel_#(channel number)_RegistrationRetry</i>			Example – Set registration retry value of VoIP 1  <i>Channel number – 1</i> <i>Value - 29</i>							
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Default 0 - 86400</td> <td></td> </tr> </tbody> </table>	Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Default 0 - 86400		<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_RegistrationRetry","value":29,"format":"Default"}]  <b>Response :</b>  @set {"path":"/Config/VoIP","value":{"Channel_1_RegistrationRetry":29}}
Name	Values/range	Description								
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number								
Format value	Default 0 - 86400									

## 16.11. Set Proxy address

<b>API :</b>  /Config/VoIP/Channel_#(channel number)_ProxyAddress			Example – Set proxy server of VoIP 1  <i>Channel number – 1</i> <i>Value - 10.90.17.123</i>									
<b>Parameters :</b>  <table border="1"><thead><tr><th>Name</th><th>Values/range</th><th>Description</th></tr></thead><tbody><tr><td>Channel number</td><td>1-4</td><td>Channel number has to be replaced with actual VoIP channel number</td></tr><tr><td>Format value</td><td>Default</td><td>Valid string value</td></tr></tbody></table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Default	Valid string value	<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_ProxyAddress","value":"10.90.17.123","format":"Default"}]  <b>Response :</b>  @set {"path":"/Config/VoIP","value":{"Channel_1_ProxyAddress":"10.90.17.123"}}
Name	Values/range	Description										
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number										
Format value	Default	Valid string value										

## 16.12. Set Proxy port

<b>API :</b>  /Config/VoIP/Channel_#(channel number)_Proxy port			Example – Set proxy port of VoIP 1  <i>Channel number – 1</i> <i>Value - 10</i>									
<b>Parameters :</b>  <table border="1"><thead><tr><th>Name</th><th>Values/range</th><th>Description</th></tr></thead><tbody><tr><td>Channel number</td><td>1-4</td><td>Channel number has to be replaced with actual VoIP channel number</td></tr><tr><td>Format value</td><td>Default 0-65535</td><td></td></tr></tbody></table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Default 0-65535		<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_ProxyPort","value":10,"format":"Default"}]  <b>Response :</b>  @set {"path":"/Config/VoIP","value":{"Channel_1_ProxyPort":10}}
Name	Values/range	Description										
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number										
Format value	Default 0-65535											

## 16.13. Set Signaling port

<b>API :</b>  /Config/VoIP/Channel_#(channel number)_SignalingPort	Example – Set signaling port of VoIP 1  <i>Channel number – 1</i> <i>Value - 10</i>									
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Default 0-65535</td> <td></td> </tr> </tbody> </table>	Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Default 0-65535		<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_SignalingPort","value":10,"format":"Default"}]  <b>Response :</b>  @set {"path":"/Config/VoIP","value":{"Channel_1_SignalingPort":10}}
Name	Values/range	Description								
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number								
Format value	Default 0-65535									

## 16.14. Set SRTP Preference

<b>API :</b>  /Config/VoIP/Channel_#(channel number)_SRTPPreference	Example – Set SRTP preference of VoIP 1  <i>Channel number – 1</i> <i>Value - optional</i>									
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Default { disabled, optional, required)</td> <td></td> </tr> </tbody> </table>	Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Default { disabled, optional, required)		<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_SRTPPreference","value":"optional","format":"Default"}]  <b>Response :</b>  @set {"path":"/Config/VoIP","value":{"Channel_1_SRTPPreference":"optional"}}
Name	Values/range	Description								
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number								
Format value	Default { disabled, optional, required)									

## 16.15. Set RTP Port

<b>API :</b>  <i>/Config/VoIP/Channel_#(channel number)_RTPPort</i>			Example – Set RTP port of VoIP 1  <i>Channel number – 1</i> <i>Value - 2000</i>								
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Default 0-65535</td> <td></td> </tr> </tbody> </table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Default 0-65535	
Name	Values/range	Description									
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number									
Format value	Default 0-65535										

## 16.16. Set RTP Port end

<b>API :</b>  <i>/Config/VoIP/Channel_#(channel number)_RTPPortEnd</i>			Example – Set RTP port end of VoIP 1  <i>Channel number – 1</i> <i>Value - 23554</i>								
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Default 0-65535</td> <td></td> </tr> </tbody> </table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Default 0-65535	
Name	Values/range	Description									
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number									
Format value	Default 0-65535										

## 16.17. Set Ring type

<b>API :</b>  /Config/VoIP/Channel_#(channel number)_RingType	Example – Set ring type of VoIP 1  <i>Channel number – 1</i> <i>Value - silent</i>									
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Default Classic, silent</td> <td></td> </tr> </tbody> </table>	Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Default Classic, silent		<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_RingType","value":"silent","format":"Default"}]  <b>Response :</b>  @set {"path":"/Config/VoIP","value":{"Channel_1_RingType":"silent"}}
Name	Values/range	Description								
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number								
Format value	Default Classic, silent									

## 16.18. Set AutoAnswerAfter option

<b>API :</b>  /Config/VoIP/Channel_#(channel number)_AutoAnswerAfter	Example – Set AutoAnswerOption of VoIP 1  <i>Channel number – 1</i> <i>Value – 2 Rings</i>									
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Default { Immediately, 1 Ring, 2 Rings, 3 Rings}</td> <td></td> </tr> </tbody> </table>	Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Default { Immediately, 1 Ring, 2 Rings, 3 Rings}		<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_AutoAnswerAfter","value":"2 Rings","format":"Default"}]  <b>Response :</b>  @set {"path":"/Config/VoIP","value":{"Channel_1_AutoAnswerAfter":"2 Rings"}}
Name	Values/range	Description								
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number								
Format value	Default { Immediately, 1 Ring, 2 Rings, 3 Rings}									

## 16.19. Set DTMFMode option

<b>API :</b>  /Config/VoIP/Channel_#(channel number)_DtmfMode			Example – Set DTMF option of VoIP 1  <i>Channel number – 1</i> <i>Value - 1</i>												
<b>Parameters :</b>  <table border="1"><thead><tr><th>Name</th><th>Values/range</th><th>Description</th></tr></thead><tbody><tr><td>Channel number</td><td>1-4</td><td>Channel number has to be replaced with actual VoIP channel number</td></tr><tr><td>Format</td><td>Default</td><td></td></tr><tr><td>value</td><td>0-3</td><td>0 – none 1-Sip info 2-In Band 3-Out of Band</td></tr></tbody></table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format	Default		value	0-3	0 – none 1-Sip info 2-In Band 3-Out of Band	<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_DtmfMode","value":1,"format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/VoIP/Channel_1_DtmfMode","value":"1"}
Name	Values/range	Description													
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number													
Format	Default														
value	0-3	0 – none 1-Sip info 2-In Band 3-Out of Band													

## 16.20. Enable/Disable DTMF Tone Mute option

<b>API :</b>  /Config/VoIP/Channel_#(channel number)_DtmfToneMute			Example – Enable DTMF Tone Mute option of VoIP 1  <i>Channel number -1</i> <i>Value - 1</i>												
<b>Parameters :</b>  <table border="1"><thead><tr><th>Name</th><th>Values/range</th><th>Description</th></tr></thead><tbody><tr><td>Channel number</td><td>1-4</td><td>Channel number has to be replaced with actual VoIP channel number</td></tr><tr><td>Format</td><td>Default</td><td></td></tr><tr><td>value</td><td>0-1</td><td></td></tr></tbody></table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format	Default		value	0-1		<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_DtmfToneMute","value":1,"format":"Norm"}]  <b>Response :</b>  @set {"format":"Norm","path":"/Config/VoIP/Channel_1_DtmfToneMute","value":"1"}
Name	Values/range	Description													
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number													
Format	Default														
value	0-1														

## 16.21. Enable/Disable DTMFFixedLength option

<b>API :</b>  /Config/VoIP/Channel_#(channel number)_DTMFFixedLength	Example – enable DTMFFixedLength option of VoIP 1  <i>Channel number – 1</i> <i>Value - 1</i>									
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Default 0-1</td> <td></td> </tr> </tbody> </table>	Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Default 0-1		<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_DTMFFixedLength","value":1,"format":"Norm"}]  <b>Response :</b>  @set {"format":"Norm","path":"/Config/VoIP/Channel_1_DTMFFixedLength","value":"1"}
Name	Values/range	Description								
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number								
Format value	Default 0-1									

## 16.22. Set DTMFOnTime value (ms)

<b>API :</b>  /Config/VoIP/Channel_#(channel number)_DTMFOnTime	Example – Set DTMFOnTime value of VoIP 1  <i>Channel number – 1</i> <i>Value - 251</i>									
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Default 50-1000</td> <td>In milliseconds</td> </tr> </tbody> </table>	Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Default 50-1000	In milliseconds	<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_DTMFOnTime","value":251,"format":"Default"}]  <b>Response :</b>  @set {"path":"/Config/VoIP","value":{"Channel_1_DTMFOnTime":251}}
Name	Values/range	Description								
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number								
Format value	Default 50-1000	In milliseconds								

## 16.23. Set DTMFOffTime value (ms)

<b>API :</b>  <i>/Config/VoIP/Channel_#(channel number)_DTMFOffTime</i>			Example – Set DTMFOffTime value of VoIP 1  <i>Channel number – 1</i> <i>Value - 500</i>											
<b>Parameters :</b> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format</td> <td>Default</td> <td></td> </tr> <tr> <td>value</td> <td>50-1000</td> <td>In milliseconds</td> </tr> </tbody> </table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format	Default		value	50-1000	In milliseconds
Name	Values/range	Description												
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number												
Format	Default													
value	50-1000	In milliseconds												
<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_DTMFOffTime","value":"500","format":"Default"}]	<b>Response :</b>  @set >{"path":"/Config/VoIP","value":{"Channel_1_DTMFOffTime":"500"}}													

## 16.24. Enable/Disable Session timer

<b>API :</b>  <i>/Config/VoIP/Channel_#(channel number)_SessionTimer</i>			Example – Enable session timer of VoIP 1  <i>Channel number – 1</i> <i>Value - 1</i>											
<b>Parameters :</b> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format</td> <td>Norm</td> <td></td> </tr> <tr> <td>value</td> <td>0-1</td> <td></td> </tr> </tbody> </table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format	Norm		value	0-1	
Name	Values/range	Description												
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number												
Format	Norm													
value	0-1													
<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_SessionTimer","value":1,"format":"Norm"}]	<b>Response :</b>  @set >{"format":"Norm","path":"/Config/VoIP/Channel_1_SessionTimer","value":1}													

## 16.25. Set DefaultTimer value

<b>API :</b>  <i>/Config/VoIP/Channel_#(channel number)_DefaultTimer</i>			Example – Set DefaultTimer value of VoIP 1  <i>Channel number – 1</i> <i>Value - 300</i>								
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Default 90-65535</td> <td>In seconds</td> </tr> </tbody> </table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Default 90-65535	In seconds
Name	Values/range	Description									
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number									
Format value	Default 90-65535	In seconds									

## 16.26. Set MinimumTimer value

<b>API :</b>  <i>/Config/VoIP/Channel_#(channel number)_MinimumTimer</i>			Example – Set MinimumTimer of VoIP 1  <i>Channel number – 1</i> <i>Value - 91</i>								
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Default 90-65535</td> <td>In seconds</td> </tr> </tbody> </table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Default 90-65535	In seconds
Name	Values/range	Description									
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number									
Format value	Default 90-65535	In seconds									

## 16.27. Enable/Disable KeepAlive option

<b>API :</b>  <i>/Config/VoIP/Channel_#(channel number)_KeepAlive</i>			Example – Enable KeepAlive of VoIP 1  <i>Channel number – 1</i> <i>Value - 1</i>								
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Default 0-1</td> <td>Enable/Disable</td> </tr> </tbody> </table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Default 0-1	Enable/Disable
Name	Values/range	Description									
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number									
Format value	Default 0-1	Enable/Disable									

## 16.28. Set KeepAliveInterval value

<b>API :</b>  <i>/Config/VoIP/Channel_#(channel number)_KeepAliveInterval</i>			Example – Set KeepAliveInterval of VoIP 1  <i>Channel number – 1</i> <i>Value - 20</i>								
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Default 20-30</td> <td>In seconds</td> </tr> </tbody> </table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Default 20-30	In seconds
Name	Values/range	Description									
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number									
Format value	Default 20-30	In seconds									

## 16.29. Enable/Disable AutoAnswer

<b>API :</b>  /Config/VoIP/Channel_#(channel number)_AutoAnswer	Example – Enable autoanswer for VoIP channel 1  <i>Channel number – 1</i> <i>Value - 1</i>									
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Norm 0-1</td> <td>Enable/Disable</td> </tr> </tbody> </table>	Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Norm 0-1	Enable/Disable	<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_AutoAnswer","value":1,"format":"Norm"}]  <b>Response :</b>  @set {"format":"Norm","path":"/Config/VoIP/Channel_1_AutoAnswer","value":1}
Name	Values/range	Description								
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number								
Format value	Norm 0-1	Enable/Disable								

## 16.30. Enable/Disable DND

<b>API :</b>  /Config/VoIP/Channel_#(channel number)_DND	Example – Enable DND  <i>Channel number – 1</i> <i>Value - 1</i>									
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Default 0-1</td> <td>0 – Disable 1 - Enable</td> </tr> </tbody> </table>	Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Default 0-1	0 – Disable 1 - Enable	<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_DND","value":1,"format":"Norm"}]  <b>Response :</b>  @set {"format":"Norm","path":"/Config/VoIP/Channel_1_DND","value":1}
Name	Values/range	Description								
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number								
Format value	Default 0-1	0 – Disable 1 - Enable								

## 16.31. Increase/Decrease Volume (Set RXGain)

<b>API :</b>  /Config/VoIP/Channel_#(channel number)_RXGain	Example – Increase volume of VoIP channel 1  Channel number – 1 Value - 3									
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Number (-12) – (12)</td> <td></td> </tr> </tbody> </table>	Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Number (-12) – (12)		<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_RXGain","value":3,"format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/VoIP/Channel_1_RXGain","value":"3"}
Name	Values/range	Description								
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number								
Format value	Number (-12) – (12)									

## 16.32. Set TXGain

<b>API :</b>  /Config/VoIP/Channel_#(channel number)_TXGain	Example – Set TXGain of of VoiP Channel 2  Channel number – 2 Value – 2									
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Number (-12)- (12)</td> <td></td> </tr> </tbody> </table>	Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Number (-12)- (12)		<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_2_TXGain","value":2,"format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/VoIP/Channel_2_TXGain","value":"2"}
Name	Values/range	Description								
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number								
Format value	Number (-12)- (12)									

### 16.33. Set TXMute

<b>API :</b>  /Config/VoIP/Channel_#(channel number)_TxMute			Example – Mute VoIP call  Channel number – 2 Value – 1
<b>Parameters :</b>			<b>Query/Command :</b>
<b>Name</b>	<b>Values/range</b>	<b>Description</b>	<b>Query/Command :</b> <pre>set [{"path":"/Config/VoIP/Channel_2_TxMute","value":1,"format":"Norm"}]</pre> <b>Response :</b> <pre>@set {"format":"Norm","path":"/Config/VoIP/Channel_2_TxMute","value":1}</pre>
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	
Format	Norm		
value	0-1	0 – Unmute 1 - Mute	

### 16.34. Set Ring volume

<b>API :</b>  /Config/VoIP/Channel_#(channel number)_RingVolume			Example - Set ring volume  <i>Channel number – 1</i> <i>Value – -12</i>
<b>Parameters :</b>			<b>Query/Command :</b>
<b>Name</b>	<b>Values/range</b>	<b>Description</b>	<b>Query/Command :</b> <pre>set [{"path":"/Config/VoIP/Channel_1_RingVolume", "value":-12,"format":"Number"}]</pre> <b>Response :</b> <pre>@set {"format":"Number","path":"/Config/VoIP/Channel_1_RingVolume", "value":-12}</pre>
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	
Format	Number		
value	(-12)- (12)	Range	

## 16.35. Set DTMF volume

<b>API :</b>  /Config/VoIP/Channel_#(channel number)_DTMFVolume			Example – Set DTMF volume  <i>Channel number – 1</i> <i>Value – 10</i>									
<b>Parameters :</b>  <table border="1"><thead><tr><th>Name</th><th>Values/range</th><th>Description</th></tr></thead><tbody><tr><td>Channel number</td><td>1-4</td><td>Channel number has to be replaced with actual VoIP channel number</td></tr><tr><td>Format value</td><td>Number (-12)- (12)</td><td>Range</td></tr></tbody></table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Number (-12)- (12)	Range	<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_DTMFVolume","value":10,"format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/VoIP/Channel_1_DTMFVolume","value":"10"}
Name	Values/range	Description										
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number										
Format value	Number (-12)- (12)	Range										

## 16.36. Get VoIP line status

<b>API :</b>  /Config/VoIP/Channel_#(channel number)_LineStatus			Example – Get VoIP line status  Channel number – 1												
<b>Parameters :</b>  <table border="1"><thead><tr><th>Name</th><th>Values/range</th><th>Description</th></tr></thead><tbody><tr><td>Channel number</td><td>1-4</td><td>Channel number has to be replaced with actual VoIP channel number</td></tr><tr><td>Format</td><td>Norm</td><td></td></tr><tr><td>Value</td><td>0-1</td><td>0 – disconnected 1-connected</td></tr></tbody></table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format	Norm		Value	0-1	0 – disconnected 1-connected	<b>Query/Command :</b>  get [{"path":"/Config/VoIP/Channel_1_LineStatus","format":"Norm"}]  <b>Response :</b>  @get {"format":"Norm","path":"/Config/VoIP/Channel_1_LineStatus","value":"1"}
Name	Values/range	Description													
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number													
Format	Norm														
Value	0-1	0 – disconnected 1-connected													

## 16.37. Get CallerId

<b>API :</b> <code>/Config/VoIP/Channel_#(channel number)_CallerId</code>			Example – Get caller id (number). This is used at call receiving end.  Channel number – 1									
<b>Parameters :</b> <table> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format</td> <td>Default</td> <td></td> </tr> </tbody> </table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format	Default		<b>Query/Command :</b>  get [{"path":"/Config/VoIP/Channel_1_CallerId","format":"Default"}]  <b>Response :</b>  @get [{"path":"/Config/VoIP","value":{"Channel_1_CallStatus":"callIdle","Channel_1_CallerId":"1002","Channel_1_DialNum":""}}]
Name	Values/range	Description										
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number										
Format	Default											

## 16.38. Get Dial number

<b>API :</b> <code>/Config/VoIP/Channel_#(channel number)_DialNum</code>			Example – Get dialed number. This is used to get dial number at dialer (caller) end.  <i>Channel number - 1</i>									
<b>Parameters :</b> <table> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format</td> <td>Number</td> <td></td> </tr> </tbody> </table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format	Number		<b>Query/Command :</b>  get [{"path":"/Config/VoIP/Channel_1_DialNum","format":"Default"}]  <b>Response :</b>  @get {"format":"Number","path":"/Config/VoIP/Channel_1_DialNum ","value":""}
Name	Values/range	Description										
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number										
Format	Number											

## 16.39. Get CallStatus

<b>API :</b> /Config/VoIP/Channel_#(channel number)_CallStatus			Example – Get call status ( VoIP channel 1)												
<b>Parameters :</b> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format</td> <td>Number</td> <td></td> </tr> <tr> <td>Value</td> <td>0- 7</td> <td>0 – callIdle 1- callToInitiated 2- callToRinging 3-callAnswerPending 4- callAnswered 5- callActive 6- callHeldLocal 7- callHeldRemote</td> </tr> </tbody> </table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format	Number		Value	0- 7	0 – callIdle 1- callToInitiated 2- callToRinging 3-callAnswerPending 4- callAnswered 5- callActive 6- callHeldLocal 7- callHeldRemote	<b>Query/Command :</b>  get [{"path":"/Config/VoIP/Channel_1_CallStatus","format":"Default"}]  <b>Response :</b>  @get >{"path":"/Config/VoIP","value":{"Channel_1_CallStatus":"callIdle"}}
Name	Values/range	Description													
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number													
Format	Number														
Value	0- 7	0 – callIdle 1- callToInitiated 2- callToRinging 3-callAnswerPending 4- callAnswered 5- callActive 6- callHeldLocal 7- callHeldRemote													

## 16.40. Get TxLevel

<b>API :</b> /Config/PeakMeters/VoIP_#(channel number)_TXLevel			Example – Read/Get TxLevel of VoIP 1 channel (Read only)  <i>Channel number - 1</i>												
<b>Parameters :</b> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format</td> <td>Number</td> <td></td> </tr> <tr> <td>value</td> <td>(-80) - 10</td> <td>Receiving value ranges</td> </tr> </tbody> </table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format	Number		value	(-80) - 10	Receiving value ranges	<b>Query/Command :</b>  get [{"path":"/Config/PeakMeters/VoIP_1_TXLevel","format":"Number"}]  <b>Response :</b>  @get >{"format":"Number","path":"/Config/PeakMeters/VoIP_1_TXLevel","value":"-80"}
Name	Values/range	Description													
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number													
Format	Number														
value	(-80) - 10	Receiving value ranges													

## 16.41. Get RxLevel

<b>API :</b>  /Config/VoIP/Channel_#(channel number)_RXLevel	Example - Read/Get RxLevel of VoIP 1 channel (Read only)  <i>Channel number - 1</i>									
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Number (-80) - 10</td> <td>Receiving value ranges</td> </tr> </tbody> </table>	Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Number (-80) - 10	Receiving value ranges	<b>Query/Command :</b>  get [{"path":"/Config/PeakMeters/VoIP_1_RXLevel", "format":"Number"}]  <b>Response :</b>  @get [{"format":"Number","path":"/Config/PeakMeters/VoIP_1_RXLevel","value": "-80"}]
Name	Values/range	Description								
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number								
Format value	Number (-80) - 10	Receiving value ranges								

## 16.42. Set Key pressed value

<b>API : Need to send two commands Press and Release</b>  /Config/VoIP/Channel_#(channel number)_keyPress	Example – Press ‘2’ of VoIP channel 1  <i>Channel number - 1</i> <i>Value – “2 Key” – Press, “None” - Release</i>									
<b>Parameters :</b>  <table border="1"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Default  0 Key 1 Key 2 Key 3 Key 4 Key 5 Key</td> <td>0 – “0 Key” 1- “1 Key” 2-“2 Key” 3-“3 Key” 4-“4 Key” 5-“5 Key”</td> </tr> </tbody> </table>	Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Default  0 Key 1 Key 2 Key 3 Key 4 Key 5 Key	0 – “0 Key” 1- “1 Key” 2-“2 Key” 3-“3 Key” 4-“4 Key” 5-“5 Key”	<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_keyPress","value":"2 Key","format":"Default"}]  set [{"path":"/Config/VoIP/Channel_1_keyPress","value": "None", "format": "Default"}]  <b>Response :</b>  @set {"path":"/Config/VoIP","value":{"Channel_1_keyPress": "2 Key"}}
Name	Values/range	Description								
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number								
Format value	Default  0 Key 1 Key 2 Key 3 Key 4 Key 5 Key	0 – “0 Key” 1- “1 Key” 2-“2 Key” 3-“3 Key” 4-“4 Key” 5-“5 Key”								

	6 Key 7 Key 8 Key 9 Key *Key # Key None	6-“6 Key” 7-“7 Key” 8-“8 Key” 9-“9 Key” *-“* Key” #-“# Key” Release – “None”	@set {"path":"/Config/VoIP","value":{"Channel_1_key Press":"None"}}
--	---	--	--

## 16.43. Dial (Call)

<b>API : Need to send two commands Press and Release</b>  <code>/Config/VoIP/Channel_#(channel number)_Dial</code>			Example - Dial once number/key is defined . Dial VoIP 1  <i>Channel number – 1</i> <i>Value – 1 – Press , 0 - Release</i>
<b>Parameters :</b>			<b>Query/Command :</b>
<b>Name</b>	<b>Values/range</b>	<b>Description</b>	<p><b>set</b> [{"path":"/Config/VoIP/Channel_1_Dial","value":1,"format":"Norm"}]</p> <p><b>set</b> [{"path":"/Config/VoIP/Channel_1_Dial","value":0,"format":"Norm"}]</p> <p><b>Response :</b></p> <p><b>@set</b> {"format":"Norm","path":"/Config/VoIP/Channel_1_Dial","value":1}</p>

## 16.44. Hangup/Reject the call

<b>API : Need to send two commands Press and Release</b>  <i>/Config/VoIP/Channel_#(channel number)_Hangup</i>			Example - End/Hangup the VoIP Call ( VoIP channel 1)  <i>Channel number – 1</i> <i>Value - 1 – Press , 0 - Release</i>									
<b>Parameters :</b> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Number 1, 0</td> <td>1 – button pressed 0 – button released</td> </tr> </tbody> </table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Number 1, 0	1 – button pressed 0 – button released	<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_Hangup","value":1,"format":"Norm"}]  set [{"path":"/Config/VoIP/Channel_1_Hangup","value":0,"format":"Norm"}]
Name	Values/range	Description										
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number										
Format value	Number 1, 0	1 – button pressed 0 – button released										
<b>Response :</b>  @set {"format":"Norm","path":"/Config/VoIP/Channel_1_Hangup","value":"1"}  @set {"format":"Norm","path":"/Config/VoIP/Channel_1_Hangup","value":"0"}												

## 16.45. Hold the call

<b>API : Need to send two commands Press and Release</b>  <i>/Config/VoIP/Channel_#(channel number)_Hold</i>			Example – Hold the call ( VoIP channel 1)  <i>Channel number – 1</i> <i>Value - 1 – Press , 0 - Release</i>						
<b>Parameters :</b> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> </tbody> </table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_Hold","value":1,"format":"Norm"}]
Name	Values/range	Description							
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number							

Format value	Number 1, 0	1 – button pressed 0 – button released	<pre>set [{"path":"/Config/VoIP/Channel_1_Hold","value":0,"format":"Norm"}]</pre> <p><b>Response :</b></p> <pre>@set {"format":"Norm","path":"/Config/VoIP/Channel_1_Hold","value":1}</pre> <pre>@set {"format":"Norm","path":"/Config/VoIP/Channel_1_Hold","value":0}</pre>
-----------------	----------------	---	--

## 16.46. Redial the number

<b>API : Need to send two commands Press and Release</b>  <i>/Config/VoIP/Channel_#(channel number)_Redial</i>			Example - Redial the last called number ( VoIP channel 1)  <i>Channel number – 1</i> <i>Value - 1 – Press , 0 - Release</i>									
<b>Parameters :</b> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Number 1, 0</td> <td>1 – button pressed 0 – button released</td> </tr> </tbody> </table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Number 1, 0	1 – button pressed 0 – button released	<b>Query/Command :</b> <pre>set [{"path":"/Config/VoIP/Channel_1_Redial","value":1,"format":"Norm"}]</pre> <pre>set [{"path":"/Config/VoIP/Channel_1_Redial","value":0,"format":"Norm"}]</pre> <p><b>Response :</b></p> <pre>@set {"format":"Norm","path":"/Config/VoIP/Channel_1_Redial","value":1}</pre> <pre>@set {"format":"Norm","path":"/Config/VoIP/Channel_1_Redial","value":0}</pre>
Name	Values/range	Description										
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number										
Format value	Number 1, 0	1 – button pressed 0 – button released										
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number										
Format value	Number 1, 0	1 – button pressed 0 – button released										

## 16.47. Resume the call

<b>API : Need to send two commands Press and Release</b>  /Config/VoIP/Channel_#(channel number)_Resume	Example – Resume the VoIP channel 1 call  <i>Channel number – 1</i> <i>Value - 1 – Press , 0 - Release</i>									
<b>Parameters :</b>  <table> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Number 1, 0</td> <td>1 – button pressed 0 – button released</td> </tr> </tbody> </table>	Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Number 1, 0	1 – button pressed 0 – button released	<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_Resume","value":1,"format":"Norm"}]  set [{"path":"/Config/VoIP/Channel_1_Resume","value":1,"format":"Norm"}]  <b>Response :</b>  @set {"format":"Norm","path":"/Config/VoIP/Channel_1_Resume","value":"1"}  @set {"format":"Norm","path":"/Config/VoIP/Channel_1_Resume","value":"0"}
Name	Values/range	Description								
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number								
Format value	Number 1, 0	1 – button pressed 0 – button released								

## 16.48. Answer the call

<b>API : Need to send two commands Press and Release</b>  /Config/VoIP/Channel_#(channel number)_Answer	Example - Answer the incoming call  <i>Channel number – 1</i> <i>Value -1 – Press , 0 - Release</i>						
<b>Parameters :</b>  <table> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> </tbody> </table>	Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	<b>Query/Command :</b>  set [{"path":"/Config/VoIP/Channel_1_Answer","value":1,"format":"Norm"}]  set [{"path":"/Config/VoIP/Channel_1_Answer","value":1,"format":"Norm"}]
Name	Values/range	Description					
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number					

Format value	Number 1, 0	1 – button pressed 0 – button released	<b>Response :</b> @set { "format": "Norm", "path": "/Config/VoIP/Channel_1_Answer", "value": "1" }  @set { "format": "Norm", "path": "/Config/VoIP/Channel_1_Answer", "value": "0" }
--------------	----------------	---	---

## 16.49. Delete dial number field

<b>API : It will delete last digit from dial number field. Need to send two commands Press and Release</b>  /Config/VoIP/Channel_#(channel number)_Delete			Example – Delete last digit from dial number field ( VoIP channel 1)  <i>Channel number – 1</i> <i>Value -1 – Press , 0 - Release</i>									
<b>Parameters :</b> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Name</th> <th>Values/range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Channel number</td> <td>1-4</td> <td>Channel number has to be replaced with actual VoIP channel number</td> </tr> <tr> <td>Format value</td> <td>Number 1, 0</td> <td>1 – button pressed 0 – button released</td> </tr> </tbody> </table>			Name	Values/range	Description	Channel number	1-4	Channel number has to be replaced with actual VoIP channel number	Format value	Number 1, 0	1 – button pressed 0 – button released	<b>Query/Command :</b>  set [ { "path": "/Config/VoIP/Channel_1_Delete", "value": 1, "format": "Norm" } ]  set [ { "path": "/Config/VoIP/Channel_1_Delete", "value": 0, "format": "Norm" } ]  <b>Response :</b>  @set { "format": "Norm", "path": "/Config/VoIP/Channel_1_Delete", "value": "1" }  @set { "format": "Norm", "path": "/Config/VoIP/Channel_1_Delete", "value": "0" }
Name	Values/range	Description										
Channel number	1-4	Channel number has to be replaced with actual VoIP channel number										
Format value	Number 1, 0	1 – button pressed 0 – button released										

## 16.50. Set Transport type (General VoIP settings screen)

<b>API :</b>  /Config/VoIP/TransportType			Example - Set Transport type  <i>Value - tcp</i>
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	<b>set</b> [{"path":"/Config/VoIP/TransportType","value":"tcp","format":"Default"}]  <b>Response :</b>  @set {"format":"Norm","path":"/Config/VoIP/TransportType ","value":"tcp"}

## 16.51. Set T1 Timer

<b>API :</b>  /Config/VoIP/T1Timer			Example - Set T1 Timer  <i>Value - 500</i>
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	<b>set</b> [{"path":"/Config/VoIP/ T1Timer ","value":"500","format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/VoIP/ T1Timer ","value":"500"}

## 16.52. Set T2 Timer

API : /Config/VoIP/T2imer			Example - Set T2 timer  <i>Value - 4000</i>
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	<b>set [{"path":"/Config/VoIP/ T2imer","value":"4000","format":"Number"}]</b>  <b>Response :</b>  <i>@set {"format":"Number","path":"/Config/VoIP/ T2imer ","value":"4000"}</i>
Format	Default		
value	100-10000	In milliseconds	

## 16.53. Set T4 Timer

API : /Config/VoIP/T4Timer			Example - Set T4 timer  <i>Value - 5000</i>
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	<b>set [ {"path":"/Config/VoIP/ T4Timer","value":"5000","format":"Number"}]</b>  <b>Response :</b>  <i>@set {"format":"Number","path":"/Config/VoIP/ T4Timer ","value":"5000"}</i>
Format	Default		
value	300-30000	In milliseconds	

## 16.54. Set TD Timer

API : /Config/VoIP/TDTimer			Example - Set TD Timer  <i>Value - 5000</i>
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	<b>set [ {"path":"/Config/VoIP/ TDTimer","value":"5000","format":"Number"}]</b>  <b>Response :</b>  <i>@set {"format":"Number","path":"/Config/VoIP/ TDTimer ","value":"5000"}</i>
Format	Default		
value	400-60000	In milliseconds	

## 16.55. Set RPort

<b>API :</b> /Config/VoIP/RPort			Example - Set RPort  <i>Value - 50</i>
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	set [{"path":"/Config/VoIP/ RPort","value":"50","format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/VoIP/ RPort ","value":"50"}

## 16.56. Set Stun Port

<b>API :</b> /Config/VoIP/StunPort			Example - Set stun port number  <i>Value - 50</i>
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	set [{"path":"/Config/VoIP/ StunPort ","value":"50","format":"Number"}]  <b>Response :</b>  @set {"format":"Number","path":"/Config/VoIP/ StunPort ","value":"50"}

## 16.57. Set Stun Server

<b>API :</b> /Config/VoIP/StunServer			Example - Set Stun server  <i>Value – stun.server.com</i>
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	set [{"path":"/Config/VoIP/ StunServer ","value":" stun.server.com ","format":"Default"}]  <b>Response :</b>  @set {"format":"Default","path":"/Config/VoIP/ StunPort ","value":" stun.server.com "}

## 16.58. Get MAC address

API :  /commonConfig/nwInterfaces/i2/mac			Example -
<b>Parameters :</b>			<b>Query/Command :</b>
Name	Values/range	Description	<b>Response :</b>
Format value	Default		

## 17. Examples (Websocket)

### 17.1. Initializing connection steps

Connection must be established before sending or receiving the values from device.

**Steps to initialize connection with DCP 555 –**

**Step 1)** Open WebSocket connection

URL: ws://<IP>:<PORT>

**Step 2)** Getting sessionId from httprequest ( refer 1.1 section)

**Step 3)** Passing sessionID to WS connection

WS SEND: sessionID <sessionID>

WS RESPONSE: WS {"status":200,"description":"login was success"}

### 17.2. Setting a value

Once WebSocket connection is initialized with valid sessionID. Call HCommand to set a value.

e.g. WS SEND: set {"path":"/Config/Channel1Level/Mute","value":1,"format":"Norm"}

WS RESPONSE: @set {"format":"Norm","path":"/Config/Channel1Level/Mute","value":1"}

### 17.3. Getting a value

To get value of SV use as below:

e.g. WS SEND: get {"path":"/Config/Channel1Level/Mute","format":"Norm"}

WS RESPONSE: @get {"format":"Norm","path":"/Config/Channel1Level/Mute","value":0"}

### 17.4. Subscription steps

For sensor based SVs, subscription can be done as following:

**Step 1)** To subscribe for an event:

WS SEND: subscribe {"path":"/Config/Channel1Level/Mute","format":"Norm"}

WS RESPONSE: @subscribe {"format":"Norm","path":"/Config/Channel1Level/Mute","value":1"}

**Step 2)** Notification:



---

On value change, we get below publish response.

WS RESPONSE: publish {"format":"Norm","path":"/Config/Channel1Level/Mute","value":"0"}

**Step 3) Acknowledging publish response**

Each **publish** has to get acknowledged with below command. without acknowledgement system will not publish next changed events.

WS SEND: @publish

## 17.5. Remove Subscription

WS SEND: unsubscribe {"path":"/Config/Channel1Level/Mute","format":"Norm"}


WS RESPONSE: @unsubscribe {"format":"Norm","path":"/Config/Channel1Level/Mute"}

## 18. Examples (TCP via Telnet)


### 18.1. Initialize TCP connection

- Input the IP address of the device (visible on DCP555 device panel).
- Port number should be **4197**.
- Connection type should be Telnet.

#### 18.1.1. By using Putty tool



#### 18.1.2. By using CMD



The screenshot shows a Windows Command Prompt window. The title bar says 'C:\Windows\system32\cmd.exe'. The text area displays:

```
Microsoft Windows [Version 10.0.14393]
(c) 2016 Microsoft Corporation. All rights reserved.

C:\Users\rmistry>telnet 10.90.76.65 4197
```

## 18.2. Login to DCP 555 device

Login to your device(DCP555) by sending command :

```
exec {"path":"/","command":"login","arguments":["administrator","administrator"]}
```

You will get the response from the device as shown in screen shot

```
exec {"path":"/","command":"login","arguments":["administrator","administrator"]}
@exec {"arguments":"Login OK","command":"login","path":"/"}
```

## 18.3. Send Commands

After successful login, the device (DCP555) is ready for command exchange. Use the API document for details. Examples for Get, Set and Subscribe are captured in the screenshot:

```
get [{"path":"/Config/Blulink/OutputPortStatus","format":"Default"}]
@get {"path":"/Config/Blulink","value":{"OutputPortStatus":"Connected"}}

set [{"path":"/Config/MatrixRouter/Channel_3_AGC_TargetLevel","value":"-13","format":"Number"}]
@set {"format":"Number","path":"/Config/MatrixRouter/Channel_3_AGC_TargetLevel",
"value": "-13" }

subscribe [{"path":"/fwUpdStatus","format":"Number"}]
@subscribe {"format":"Number","path":"/fwUpdStatus","value": "0"}
```